D16B2–03

DTC	P1335/13	Crankshaft Position Sensor Circuit Malfunction (During engine running)

CIRCUIT DESCRIPTION

Refer to DTC P0335/12, 13 on page DI–65.

DTC No.	DTC Detecting Condition	Trouble Area
P1335/13	No crankshaft position sensor signal to engine (and ECT) ECU with engine speed 1,500 rpm or more	• Open or short in crankshaft position sensor circuit • Crankshaft position sensor • Signal plate • Engine (and ECT) ECU

WIRING DIAGRAM

Refer to DTC P0335/12, 13 on page DI–65.

INSPECTION PROCEDURE

Refer to DTC P0335/12, 13 on page DI–65