FOREWORD

This wiring diagram manual has been prepared to provide information on the electrical system of the LAND CRUISER / LAND CRUISER PRADO.

Applicable models: GRJ120, 125 Series
RZJ120, 125 Series
KDJ120, 125 Series
KZJ120 Series
LJ120, 125 Series

For service specifications and repair procedures of the above models other than those listed in this manual, refer to the following manuals;

Manual Name	Pub. No.
● LAND CRUISER / LAND CRUISER PRADO Chassis and Body Repair Manual Volume 1	RM990E1
Volume 2	RM990E2
Volume 3	RM990E3
● LAND CRUISER / LAND CRUISER PRADO Chassis and Body Repair Manual Supplement	RM1017E
● 1GR−FE Engine Repair Manual	RM1005E
● 3RZ−FE Engine Repair Manual	RM991E
● 1KD−FTV Engine Repair Manual	RM992E
● 1KZ−TE Engine Repair Manual	RM997E
● 5L−E Engine Repair Manual	RM993E
● LAND CRUISER / LAND CRUISER PRADO New Car Features	NCF233E
● LAND CRUISER / LAND CRUISER PRADO New Car Features Supplement	NCF236E

All information in this manual is based on the latest product information at the time of publication. However, specifications and procedures are subject to change without notice.

TOYOTA MOTOR CORPORATION

NOTICE

When handling supplemental restraint system components (removal, installation or inspection, etc.), always follow the direction given in the repair manuals listed above to prevent accidents and supplemental restraint system malfunction.