Driver Side J/B (See Page 26 (LHD), 28 (RHD))

Fuse		System	Page
7.5A	ACC	ABS	572
		Accessory Meter	642
		Air Conditioner (Automatic A/C)	694
		Back−Up Light (Diesel)	346
		Back−Up Light (Gasoline)	342
		Cigarette Lighter and Power Outlet	624
		Combination Meter	672
		Cruise Control (1GR−FE)	512
		Cruise Control (1KD−FTV)	520
		Cruise Control (1KZ−TE)	528
		Door Lock Control and Theft Deterrent (LHD)	426
		Door Lock Control and Theft Deterrent (RHD)	438
		Double Locking	450
		ECT and A/T Indicator (1GR−FE)	458
		ECT and A/T Indicator (1KZ−TE)	500
		ECT and A/T Indicator (3RZ−FE Unleaded Gasoline)	470
		Engine Control (1GR−FE)	162
		Engine Control (1KZ−TE)	210
		Engine Control (3RZ−FE Unleaded Gasoline)	174
		Headlight (w/ Daytime Running Light)	288
		Headlight (w/o Daytime Running Light)	294
		Interior Light	318
		Key Reminder and Seat Belt Warning	350
		Light Auto Turn Off	306
		Moon Roof	608
		Multiplex Communication System (LHD)	240
		Multiplex Communication System (RHD)	264
		Navigation System (LHD)	648
		Navigation System (RHD)	654
		Option Connector (Wireless Door Lock Control)	418
		Power Window (LHD w/ Jam Protection)	370
		Power Window (LHD w/o Jam Protection)	378
		Power Window (RHD w/ Jam Protection)	384
		Power Window (RHD w/o Jam Protection)	392
		Radio and Player (Built−in Type Amplifier)	668
		Radio and Player (Separate Type Amplifier)	660
		Rear Differential Lock	596
		Remote Control Mirror	614
		Shift Lock	590
		Trailer Towing	636
		VSC (RHD)	562
		Wireless Door Lock Control (LHD)	398

* These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
7.5A	ACC	Wireless Door Lock Control (RHD)	408
		4WD	604
7.5A	GAUGE	ABS	572
		Accessory Meter	642
		Active Height Control Suspension and Electric Modulated Air Suspension	580
		Air Conditioner (Automatic A/C)	694
		Center Differential Lock	592
		Charging (Gasoline)	152
		Charging (1KD−FTV)	154
		Charging (1KZ−TE, 5L−E)	158
		Combination Meter	672
		Cruise Control (1GR−FE)	512
		Cruise Control (1KD−FTV)	520
		Cruise Control (1KZ−TE)	528
		Door Lock Control and Theft Deterrent (LHD)	426
		Door Lock Control and Theft Deterrent (RHD)	438
		ECT and A/T Indicator (1GR−FE)	458
		ECT and A/T Indicator (1KD−FTV)	488
		ECT and A/T Indicator (1KZ−TE)	500
		ECT and A/T Indicator (3RZ−FE Leaded Gasoline)	480
		ECT and A/T Indicator (3RZ−FE Unleaded Gasoline)	470
		Engine Control (1GR−FE)	162
		Engine Control (1KD−FTV)	196
		Engine Control (1KZ−TE)	210
		Engine Control (3RZ−FE Leaded Gasoline)	186
		Engine Control (3RZ−FE Unleaded Gasoline)	174
		Engine Control (5L−E)	222
		Interior Light	318
		Key Reminder and Seat Belt Warning	350
		Moon Roof	608
		Multiplex Communication System (LHD)	240
		Multiplex Communication System (RHD)	264
		Navigation System (LHD)	648
		Navigation System (RHD)	654
		Radio and Player (Separate Type Amplifier)	660
		Rear Differential Lock	596
		SRS	535
		Taillight and Illumination	326
		Viscous Heater	688
		VSC (LHD A/T)	542
		VSC (LHD M/T)	552
		VSC (RHD)	562
		4WD	604

* These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
7.5A	STA	ECT and A/T Indicator (1GR−FE)	458
		ECT and A/T Indicator (1KD−FTV)	488
		ECT and A/T Indicator (1KZ−TE)	500
		ECT and A/T Indicator (3RZ−FE Leaded Gasoline)	480
		ECT and A/T Indicator (3RZ−FE Unleaded Gasoline)	470
		Engine Control (1GR−FE)	162
		Engine Control (1KD−FTV)	196
		Engine Control (1KZ−TE)	210
		Engine Control (3RZ−FE Leaded Gasoline)	186
		Engine Control (3RZ−FE Unleaded Gasoline)	174
		Engine Control (5L−E)	222
		Starting (Diesel)	138
		Starting (1GR−FE)	132
		Starting (3RZ−FE)	134
10A	CIG	Cigarette Lighter and Power Outlet	624
10A	ECU−IG	ABS	572
		Accessory Meter	642
		Active Height Control Suspension and Electric Modulated Air Suspension	580
		Door Lock Control and Theft Deterrent (LHD)	426
		Door Lock Control and Theft Deterrent (RHD)	438
		Double Locking	450
		Engine Immobiliser (Except 3RZ−FE Unleaded Gasoline)	236
		Engine Immobiliser (3RZ−FE Unleaded Gasoline)	232
		Headlight (w/ Daytime Running Light)	288
		Headlight (w/o Daytime Running Light)	294
		Interior Light	318
		Key Reminder and Seat Belt Warning	350
		Light Auto Turn Off	306
		Moon Roof	608
		Multiplex Communication System (LHD)	240
		Multiplex Communication System (RHD)	264
		Navigation System (LHD)	648
		Navigation System (RHD)	654
		Option Connector (Wireless Door Lock Control)	418
		Power Window (LHD w/ Jam Protection)	370
		Power Window (LHD w/o Jam Protection)	378
		Power Window (RHD w/ Jam Protection)	384
		Power Window (RHD w/o Jam Protection)	392
		Shift Lock	590
		Stop Light	338
		Trailer Towing	636
		VSC (LHD A/T)	542
		VSC (LHD M/T)	552
		VSC (RHD)	562

* These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
10A	ECU–IG	Wireless Door Lock Control (LHD)	398
		Wireless Door Lock Control (RHD)	408
10A	IGN	Cruise Control (1GR–FE)	512
		Cruise Control (1KD–FTV)	520
		Cruise Control (1KZ–TE)	528
		ECT and A/T Indicator (1GR–FE)	458
		ECT and A/T Indicator (1KD–FTV)	488
		ECT and A/T Indicator (1KZ–TE)	500
		ECT and A/T Indicator (3RZ–FE Leaded Gasoline)	480
		ECT and A/T Indicator (3RZ–FE Unleaded Gasoline)	470
		Engine Control (1GR–FE)	162
		Engine Control (1KD–FTV)	196
		Engine Control (1KZ–TE)	210
		Engine Control (3RZ–FE Leaded Gasoline)	186
		Engine Control (3RZ–FE Unleaded Gasoline)	174
		Engine Control (5L–E)	222
		VSC (LHD A/T)	542
		VSC (LHD M/T)	552
		VSC (RHD)	562
10A	IG1	Air Conditioner (Automatic A/C)	694
		Air Conditioner (Manual A/C Except 1GR–FE)	712
		Air Conditioner (Manual A/C 1GR–FE)	708
		Charging (Gasoline)	152
		Condenser Fan	684
		Cruise Control (1KD–FTV)	520
		Cruise Control (1KZ–TE)	528
		Rear Window Defogger	620
10A	IG1 NO.2	ABS	572
		Accessory Meter	642
		Air Conditioner (Automatic A/C)	694
		Air Conditioner (Manual A/C Except 1GR–FE)	712
		Air Conditioner (Manual A/C 1GR–FE)	708
		Back–Up Light (Diesel)	346
		Back–Up Light (Gasoline)	342
		Charging (1KD–FTV)	154
		Charging (1KZ–TE, 5L–E)	158
		Combination Meter	672
		Cooler Box	726
		Cruise Control (1GR–FE)	512
		Cruise Control (1KD–FTV)	520
		Cruise Control (1KZ–TE)	528
		ECT and A/T Indicator (1GR–FE)	458
		ECT and A/T Indicator (1KD–FTV)	488
		ECT and A/T Indicator (1KZ–TE)	500

* These are the page numbers of the first page on which the related system is shown.

J POWER SOURCE (Current Flow Chart)

Fuse		System	Page
10A	IG1 NO.2	ECT and A/T Indicator (3RZ−FE Leaded Gasoline)	480
		ECT and A/T Indicator (3RZ−FE Unleaded Gasoline)	470
		Engine Control (1GR−FE)	162
		Engine Control (1KD−FTV)	196
		Engine Control (1KZ−TE)	210
		Engine Control (3RZ−FE Leaded Gasoline)	186
		Engine Control (3RZ−FE Unleaded Gasoline)	174
		Engine Control (5L−E)	222
		Key Reminder and Seat Belt Warning	350
		Mirror Heater	616
		Moon Roof	608
		Multiplex Communication System (LHD)	240
		Multiplex Communication System (RHD)	264
		Navigation System (LHD)	648
		Navigation System (RHD)	654
		Radio and Player (Separate Type Amplifier)	660
		Rear Air Conditioner (Automatic A/C)	718
		Rear Air Conditioner (Manual A/C)	722
		Rear Differential Lock	596
		Seat Heater	632
		Taillight and Illumination	326
		Trailer Towing	636
		Turn Signal and Hazard Warning Light	312
		Viscous Heater	688
		VSC (LHD A/T)	542
		VSC (LHD M/T)	552
		VSC (RHD)	562
		4WD	604
10A	PANEL	Headlight (w/ Daytime Running Light)	288
		Multiplex Communication System (LHD)	240
		Multiplex Communication System (RHD)	264
		Taillight and Illumination	326
10A	SRS	SRS	535
10A	TAIL	Front Fog Light	298
		Taillight and Illumination	326
		Trailer Towing	636
15A	PWR OUTLET	Cigarette Lighter and Power Outlet	624
15A	RR WIP	Rear Wiper and Washer	368
15A	RR WSH	Rear Wiper and Washer	368
20A	D RR P/W	Multiplex Communication System (LHD)	240
		Multiplex Communication System (RHD)	264
		Power Window (LHD w/ Jam Protection)	370
		Power Window (RHD w/ Jam Protection)	384

* These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
20A	DIFF	Center Differential Lock	592
		Rear Differential Lock	596
20A	P FR P/W	Multiplex Communication System (LHD)	240
		Multiplex Communication System (RHD)	264
		Power Window (LHD w/ Jam Protection)	370
		Power Window (RHD w/ Jam Protection)	384
20A	P RR P/W	Multiplex Communication System (LHD)	240
		Multiplex Communication System (RHD)	264
		Power Window (LHD w/ Jam Protection)	370
		Power Window (RHD w/ Jam Protection)	384
20A	TEMS	Active Height Control Suspension and Electric Modulated Air Suspension	580
30A	D P/SEAT	Power Seat	628
30A	FR WIP−WSH	Front Wiper and Washer	364
		Headlight Cleaner	360
30A	P P/SEAT	Power Seat	628
30A	POWER	Moon Roof	608
		Multiplex Communication System (LHD)	240
		Multiplex Communication System (RHD)	264
		Power Window (LHD w/o Jam Protection)	378
		Power Window (RHD w/o Jam Protection)	392

Engine Room R/B (See Page 23)

Fuse		System	Page
7.5A	ALT−S	Charging (Gasoline)	152
		Charging (1KD−FTV)	154
		Charging (1KZ−TE, 5L−E)	158
7.5A	HEATER NO.2	Air Conditioner (Automatic A/C)	694
		Air Conditioner (Manual A/C Except 1GR−FE)	712
		Air Conditioner (Manual A/C 1GR−FE)	708
		Viscous Heater	688
7.5A	OBD	Engine Control (1GR−FE)	162
		Engine Control (1KD−FTV)	196
		Engine Control (1KZ−TE)	210
		Engine Control (3RZ−FE Unleaded Gasoline)	174
		Engine Control (5L−E)	222
7.5A	VISCUS	Viscous Heater	688
10A	AIRSUS NO.2	Active Height Control Suspension and Electric Modulated Air Suspension	580
10A	DOME	Accessory Meter	642
		Active Height Control Suspension and Electric Modulated Air Suspension	580
		Air Conditioner (Automatic A/C)	694
		Combination Meter	672

* These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
10A	DOME	Cruise Control (1GR−FE)	512
		Cruise Control (1KD−FTV)	520
		Cruise Control (1KZ−TE)	528
		Door Lock Control and Theft Deterrent (LHD)	426
		Door Lock Control and Theft Deterrent (RHD)	438
		ECT and A/T Indicator (1GR−FE)	458
		ECT and A/T Indicator (1KD−FTV)	488
		ECT and A/T Indicator (1KZ−TE)	500
		ECT and A/T Indicator (3RZ−FE Leaded Gasoline)	480
		ECT and A/T Indicator (3RZ−FE Unleaded Gasoline)	470
		Engine Control (1GR−FE)	162
		Engine Control (1KD−FTV)	196
		Engine Control (1KZ−TE)	210
		Engine Control (3RZ−FE Leaded Gasoline)	186
		Engine Control (3RZ−FE Unleaded Gasoline)	174
		Engine Control (5L−E)	222
		Interior Light	318
		Key Reminder and Seat Belt Warning	350
		Moon Roof	608
		Multiplex Communication System (LHD)	240
		Multiplex Communication System (RHD)	264
		Navigation System (LHD)	648
		Navigation System (RHD)	654
		Option Connector (Wireless Door Lock Control)	418
		Radio and Player (Separate Type Amplifier)	660
		Rear Differential Lock	596
		Taillight and Illumination	326
		Viscous Heater	688
		VSC (LHD A/T)	542
		VSC (RHD)	562
		Wireless Door Lock Control (LHD)	398
		Wireless Door Lock Control (RHD)	408
10A	ECU−B	Accessory Meter	642
		Active Height Control Suspension and Electric Modulated Air Suspension	580
		Air Conditioner (Automatic A/C)	694
		Cooler Box	726
		Door Lock Control and Theft Deterrent (LHD)	426
		Door Lock Control and Theft Deterrent (RHD)	438
		Double Locking	450
		Engine Immobiliser (Except 3RZ−FE Unleaded Gasoline)	236
		Engine Immobiliser (3RZ−FE Unleaded Gasoline)	232
		Headlight (w/ Daytime Running Light)	288
		Headlight (w/o Daytime Running Light)	294
		Interior Light	318

* These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
10A	ECU−B	Key Reminder and Seat Belt Warning	350
		Light Auto Turn Off	306
		Multiplex Communication System (LHD)	240
		Multiplex Communication System (RHD)	264
		Navigation System (LHD)	648
		Navigation System (RHD)	654
		Option Connector (Wireless Door Lock Control)	418
		Power Window (LHD w/ Jam Protection)	370
		Power Window (LHD w/o Jam Protection)	378
		Power Window (RHD w/ Jam Protection)	384
		Power Window (RHD w/o Jam Protection)	392
		Rear Air Conditioner (Automatic A/C)	718
		Rear Fog Light	302
		VSC (LHD A/T)	542
		VSC (LHD M/T)	552
		VSC (RHD)	562
		Wireless Door Lock Control (LHD)	398
		Wireless Door Lock Control (RHD)	408
10A	ECU−B NO.2	Door Lock Control and Theft Deterrent (LHD)	426
		Door Lock Control and Theft Deterrent (RHD)	438
		Multiplex Communication System (LHD)	240
		Multiplex Communication System (RHD)	264
10A	ETCS	Cruise Control (1GR−FE)	512
		ECT and A/T Indicator (1GR−FE)	458
		Engine Control (1GR−FE)	162
10A	HEAD(HI LH)	Headlight (w/ Daytime Running Light)	288
		Headlight (w/o Daytime Running Light)	294
		Headlight Beam Level Control	356
		Multiplex Communication System (LHD)	240
		Multiplex Communication System (RHD)	264
10A	HEAD(HI RH)	Combination Meter	672
		Headlight (w/ Daytime Running Light)	288
		Headlight (w/o Daytime Running Light)	294
		Multiplex Communication System (LHD)	240
		Multiplex Communication System (RHD)	264
		Viscous Heater	688
10A	HEAD(LO LH)	Headlight (w/ Daytime Running Light)	288
		Headlight Beam Level Control	356
		Multiplex Communication System (LHD)	240
		Viscous Heater	688
10A	HEAD(LO RH)	Headlight (w/ Daytime Running Light)	288
		Multiplex Communication System (LHD)	240
10A	HORN	Door Lock Control and Theft Deterrent (LHD)	426
		Door Lock Control and Theft Deterrent (RHD)	438

* These are the page numbers of the first page on which the related system is shown.

J POWER SOURCE (Current Flow Chart)

Fuse		System	Page
10A	HORN	Horn	626
		Multiplex Communication System (LHD)	240
		Multiplex Communication System (RHD)	264
10A	MIR HEATER	Mirror Heater	616
10A	STOP	ABS	572
		Active Height Control Suspension and Electric Modulated Air Suspension	580
		Cruise Control (1GR–FE)	512
		Cruise Control (1KD–FTV)	520
		Cruise Control (1KZ–TE)	528
		ECT and A/T Indicator (1GR–FE)	458
		ECT and A/T Indicator (1KD–FTV)	488
		ECT and A/T Indicator (1KZ–TE)	500
		ECT and A/T Indicator (3RZ–FE Leaded Gasoline)	480
		ECT and A/T Indicator (3RZ–FE Unleaded Gasoline)	470
		Engine Control (1GR–FE)	162
		Engine Control (1KD–FTV)	196
		Engine Control (1KZ–TE)	210
		Engine Control (3RZ–FE Leaded Gasoline)	186
		Engine Control (3RZ–FE Unleaded Gasoline)	174
		Engine Control (5L–E)	222
		Shift Lock	590
		Stop Light	338
		Trailer Towing	636
		VSC (LHD A/T)	542
		VSC (LHD M/T)	552
		VSC (RHD)	562
15A	A/F HEATER	Engine Control (1GR–FE)	162
15A	FR FOG	Front Fog Light	298
15A	TRN–HAZ	Trailer Towing	636
		Turn Signal and Hazard Warning Light	312
20A	CDS FAN	Condenser Fan	684
20A	D FR P/W	Door Lock Control and Theft Deterrent (LHD)	426
		Door Lock Control and Theft Deterrent (RHD)	438
		Double Locking	450
		Multiplex Communication System (LHD)	240
		Multiplex Communication System (RHD)	264
		Option Connector (Wireless Door Lock Control)	418
		Power Window (LHD w/ Jam Protection)	370
		Power Window (RHD w/ Jam Protection)	384
		Wireless Door Lock Control (LHD)	398
		Wireless Door Lock Control (RHD)	408
20A	EFI	Cruise Control (1GR–FE)	512
		Cruise Control (1KD–FTV)	520

* These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
20A	EFI	Cruise Control (1KZ–TE)	528
		ECT and A/T Indicator (1GR–FE)	458
		ECT and A/T Indicator (1KD–FTV)	488
		ECT and A/T Indicator (1KZ–TE)	500
		ECT and A/T Indicator (3RZ–FE Leaded Gasoline)	480
		ECT and A/T Indicator (3RZ–FE Unleaded Gasoline)	470
		Engine Control (1GR–FE)	162
		Engine Control (1KD–FTV)	196
		Engine Control (1KZ–TE)	210
		Engine Control (3RZ–FE Leaded Gasoline)	186
		Engine Control (3RZ–FE Unleaded Gasoline)	174
		Engine Control (5L–E)	222
20A	FUEL HEATER	Fuel Heater	160
20A	RADIO NO.1	Navigation System (LHD)	648
		Navigation System (RHD)	654
		Radio and Player (Built–in Type Amplifier)	668
		Radio and Player (Separate Type Amplifier)	660
20A	SEAT HEATER	Seat Heater	632
25A	DR/LCK	Door Lock Control and Theft Deterrent (LHD)	426
		Door Lock Control and Theft Deterrent (RHD)	438
		Double Locking	450
		Multiplex Communication System (LHD)	240
		Multiplex Communication System (RHD)	264
		Option Connector (Wireless Door Lock Control)	418
		Power Window (LHD w/ Jam Protection)	370
		Power Window (LHD w/o Jam Protection)	378
		Power Window (RHD w/ Jam Protection)	384
		Power Window (RHD w/o Jam Protection)	392
		Wireless Door Lock Control (LHD)	398
		Wireless Door Lock Control (RHD)	408
30A	ABS SOL	ABS	572
30A	AM2	Charging (Gasoline)	152
		Charging (1KD–FTV)	154
		Charging (1KZ–TE, 5L–E)	158
		Combination Meter	672
		Engine Control (1GR–FE)	162
		Engine Control (3RZ–FE Leaded Gasoline)	186
		Engine Control (3RZ–FE Unleaded Gasoline)	174
		Ignition (1GR–FE)	142
		Ignition (3RZ–FE Leaded Gasoline)	150
		Ignition (3RZ–FE Unleaded Gasoline)	146
		Starting (Diesel)	138
		Starting (1GR–FE)	132
		Starting (3RZ–FE)	134

* These are the page numbers of the first page on which the related system is shown.

J POWER SOURCE (Current Flow Chart)

Fuse		System	Page
30A	DEFOG	Engine Control (1GR−FE)	162
		Multiplex Communication System (LHD)	240
		Multiplex Communication System (RHD)	264
		Rear Window Defogger	620
30A	RADIO NO.2	Navigation System (LHD)	648
		Navigation System (RHD)	654
		Radio and Player (Separate Type Amplifier)	660
30A	RR A/C	Rear Air Conditioner (Automatic A/C)	718
		Rear Air Conditioner (Manual A/C)	722
30A	TOWING	Trailer Towing	636
40A	ABS MTR	ABS	572
		VSC (LHD A/T)	542
		VSC (LHD M/T)	552
		VSC (RHD)	562
40A	PTC−1	Viscous Heater	688
40A	PTC−2	Viscous Heater	688
40A	PTC−3	Viscous Heater	688
50A	ABS SOL	VSC (LHD A/T)	542
		VSC (LHD M/T)	552
		VSC (RHD)	562
50A	AIR SUS	Active Height Control Suspension and Electric Modulated Air Suspension	580
50A	AM1	Charging (Gasoline)	152
		Charging (1KD−FTV)	154
		Charging (1KZ−TE, 5L−E)	158
		Headlight Cleaner	360
		Starting (Diesel)	138
		Starting (1GR−FE)	132
		Starting (3RZ−FE)	134
50A	HEATER	Air Conditioner (Automatic A/C)	694
		Air Conditioner (Manual A/C Except 1GR−FE)	712
		Air Conditioner (Manual A/C 1GR−FE)	708
50A	J/B	Door Lock Control and Theft Deterrent (LHD)	426
		Door Lock Control and Theft Deterrent (RHD)	438
		Light Auto Turn Off	306
		Multiplex Communication System (LHD)	240
		Multiplex Communication System (RHD)	264
		Taillight and Illumination	326
80A	GLOW	Engine Control (1KD−FTV)	196
		Engine Control (1KZ−TE)	210
		Engine Control (5L−E)	222
120A	ALT (w/o PTC)	Charging (1KD−FTV)	154
		Charging (1KZ−TE, 5L−E)	158

∗ These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
120A	ALT (w/o PTC)	Rear Window Defogger	620
		Starting (Diesel)	138
		Starting (1GR−FE)	132
		Starting (3RZ−FE)	134
		Charging (Gasoline)	152
140A	ALT (w/ PTC)	Charging (1KD−FTV)	154
		Rear Window Defogger	620
		Starting (Diesel)	138

* These are the page numbers of the first page on which the related system is shown.