ABBREVIATIONS

The following abbreviations are used in this manual.

4WD	=	Four Wheel Drive Vehicles
A/C	=	Air Conditioner
A/T	=	Automatic Transmission
ABS	=	Anti−Lock Brake System
ACIS	=	Acoustic Control Induction System
BA	=	Brake Assist
CD	=	Compact Disc
DIFF.	=	Differential
DLC3	=	Data Link Connector 3
ECT	=	Electronic Control Transmission
ECU	=	Electronic Control Unit
EGR	=	Exhaust Gas Recirculation
EVAP	=	Evaporative Emission
J/B	=	Junction Block
LH	=	Left−Hand
LHD	=	Left−Hand Drive
M/T	=	Manual Transmission
PTC	=	Positive Temperature Coefficient
R/B	=	Relay Block
RH	=	Right−Hand
RHD	=	Right−Hand Drive
SRS	=	Supplemental Restraint System
SW	=	Switch
TEMP.	=	Temperature
TRC	=	Traction Control
VRV	=	Vacuum Regulating Valve
VSC	=	Vehicle Stability Control
VSV	=	Vacuum Switching Valve
VVT	=	Variable Valve Timing
w/	=	With
w/o	=	Without

* The titles given inside the components are the names of the terminals (terminal codes) and are not treated as being abbreviations.