G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number
A 1	A/C Ambient Temp. Sensor	90980–11070
A 2	A/C Condenser Fan Motor	90980–11237
A 3	A/C Lock Sensor	90980–11016
	A/C Magnetic Clutch	
A 4	A/C Magnetic Clutch	90980–11271
A 5	A/C Magnetic Valve	90980–11075
A 6	A/T Oil Temp. Sensor (1KZ–TE)	90980–11025
	A/T Oil Temp. Sensor (2TR–FE)	90980–11162
A 7	ABS & BA & TRC & VSC Actuator	90980–11413
A 8	ABS & BA & TRC & VSC Actuator	90980–10895
A 9	ABS & BA & TRC & VSC Actuator	90980–11151
A10	ABS Speed Sensor Front LH	90980–11003
A11	ABS Speed Sensor Front RH	
A12	Absorber Control Actuator Front LH	90980–11929
A13	Absorber Control Actuator Front RH	
A14	Air Flow Meter (1GR–FE, 1KD–FTV)	90980–11317
	Air Flow Meter (2TR–FE)	90980–12292
A16	Airbag Sensor Front LH	90980–11856
A17	Airbag Sensor Front RH	
A18	Alternator (1GR–FE)	90980–09372
	Alternator (1KD–FTV)	90980–09213
	Alternator (2TR–FE, 1KZ–TE, 5L–E)	90980–09212
A19	Alternator (1GR–FE)	90980–11964
	Alternator (1KZ–TE, 5L–E)	90980–11349
	Alternator (2TR–FE, 1KD–FTV)	90980–11964
A20	A/C Amplifier (Except 1KD–FTV)	90980–12259
	A/C Amplifier (1KD–FTV)	90980–10803
A21	A/C Control Assembly (w/o Navigation System)	90980–12151
	A/C ECU (w/ Navigation System)	
A22	A/C Control Assembly (w/o Navigation System)	90980–12149
	A/C ECU (w/ Navigation System)	
A23	A/C Control Assembly (w/o Navigation System)	90980–12150
	A/C ECU (w/ Navigation System)	
A24	A/C Room Temp. Sensor	90980–11918
A25	A/C Solar Sensor	90980–12056
A26	A/C Thermistor	90980–11918
A27	A/T Shift Indicator	90980–11911
A28	Accel Position Sensor	90980–11858
A29	Acceleration Control Sensor Front	90980–10845
A30	Accessory Meter	90980–11911
A31	Air Inlet Control Servo Motor	90980–11909
A32	Air Mix Control Servo Motor LH	
A33	Air Mix Control Servo Motor RH	
A34	Air Vent Mode Control Servo Motor	

Code	Part Name	Part Number
A35	Airbag Sensor Assembly (w/ Side Airbag)	82824–50160
	Airbag Sensor Assembly (w/o Side Airbag)	90980–11869
A36	Airbag Sensor Assembly	90980–11872
A37	Airbag Sensor Assembly (w/ Side Airbag)	82824–50150
	Airbag Sensor Assembly (w/o Side Airbag)	90980–11867
A38	Airbag Squib (Front Passenger Airbag Assembly)	90980–12160
A39	Airbag Squib (Steering Wheel Pad)	
A40	Antenna Amplifier	90980–11146
A41	Ashtray Illumination	90980–10825
A42	ABS Speed Sensor Rear (3–Door)	90980–10941
	ABS Speed Sensor Rear (5–Door)	90980–10942
A43	Absorber Control Actuator Rear LH	90980–11930
A44	Absorber Control Actuator Rear RH	
A45	Acceleration Control Sensor Rear	90980–10845
A46	Air Fuel Ratio Sensor (Bank 1 Sensor 1)	90980–10869
A47	Air Fuel Ratio Sensor (Bank 2 Sensor 1)	
A48	Air Fuel Ratio Sensor (Bank 1 Sensor 1)	90980–11178
A49	Air Injection Control Driver	90980–12068
A50	Air Injection Control Driver	90980–11858
A51	Air Pump	90980–11032
A52	Air Switching Valve	90980–11149
A53	Air Vent Control Servo Motor	90980–11156
A54	Air Vent Control Servo Motor	90980–12303
B 1	Back–Up Light SW	90980–11250
B 2	Brake Fluid Level Warning SW (w/ VSC Except 1KZ–TE)	90980–11156
	Brake Fluid Level Warning SW (w/ VSC 1KZ–TE)	90980–11009
	Brake Fluid Level Warning SW (w/o VSC)	90980–11207
B 3	Brake Vacuum Warning SW	90980–11252
B 4	Blower Motor Linear Controller	90980–11676
B 5	Blower Resistor	90980–11136
B 6	Blower SW	90980–10877
B 7	Body ECU	90980–12151
B 8	Body ECU	90980–12149
B 9	Body ECU	90980–12150
B10	Back Door Courtesy SW	90980–10871
B11	Back Door Key Lock and Unlock SW	90980–12226
	Back Door Lock Motor	
	Back Door Unlock Detection SW	
B12	Buckle SW LH	90980–10795
	Occupant Detection Sensor	
B13	Buckle SW LH	90980–12257
	Seat Position Sensor	
B14	Buckle SW RH	90980–10795
	Occupant Detection Sensor	

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number
B15	Buckle SW RH	90980–12257
	Seat Position Sensor	
C 1	Camshaft Position Sensor	90980–10947
C 3	Crankshaft Position Sensor (1GR–FE)	90980–12028
	Crankshaft Position Sensor (1KZ–TE, 5L–E)	90980–11162
	Crankshaft Position Sensor (2TR–FE, 1KD–FTV)	90980–11016
C 4	CD Automatic Changer	90980–12262
C 5	Center Diff. Lock Control SW	90980–11013
C 6	Center Diff. Lock ECU	90980–10801
C 7	Cigarette Lighter	90980–10760
C 8	Cigarette Lighter Illumination	90980–11148
C 9	Combination Meter	82824–35030
C10	Combination Meter	82824–35040
C11	Combination Meter	82824–35030
C12	Combination Meter	82824–35040
C13	Combination SW	90980–12183
C14	Combination SW (LH Turn Lever Type)	90980–11672
	Combination SW (RH Turn Lever Type)	90980–11671
C15	Combination SW	90980–11594
C16	Cool Box Amplifier	90980–10801
C17	Cool Box Motor	90980–10825
C18	Cool Box SW	90980–10933
C19	Cool Box Thermistor	90980–10216
C20	Cruise Control Clutch SW	90980–10906
C21	Curtain Shield Airbag Squib LH	90980–12219
C22	Curtain Shield Airbag Squib RH	
C23	Camshaft Timing Oil Control Valve LH	90980–11162
C24	Camshaft Timing Oil Control Valve RH	
C25	Cool Box Magnetic Valve	90980–11075
C26	Camshaft Timing Oil Control Valve	90980–11162
D 1	Detection SW (Transfer 4WD Position)	90980–11156
D 2	Detection SW (Transfer L4 Position)	
D 3	Detection SW (Transfer Neutral Position)	90980–10923
D 4	Deceleration Sensor	90980–10845
D 5	Diode (Front Fog Light)	90980–10962
D 6	DLC3	90980–11978
D 7	Double Door Lock Control Relay	90980–10807
D 8	Downhill Assist Control SW	90980–11013
D 9	Detection SW (Rear Diff. Lock)	90980–11250
D10	Door Control Receiver	90980–11909
D11	Door Courtesy Light Front LH	90980–11148
D12	Door Courtesy Light Front RH	
D13	Door Courtesy Light Rear LH	
D14	Door Courtesy Light Rear RH	

Code	Part Name	Part Number
D15	Door Courtesy SW Front LH	90980–10871
D16	Door Courtesy SW Front RH	
D17	Door Courtesy SW Rear LH	
D18	Door Courtesy SW Rear RH	
D19	Door Key Lock and Unlock SW Front LH	90980–12226
	Door Lock Motor Front LH	
	Door Unlock Detection SW Front LH	
	Double Door Lock Motor Front LH	
	Position SW Front LH	
D20	Door Key Lock and Unlock SW Front RH	
	Door Lock Motor Front RH	
	Door Unlock Detection SW Front RH	
	Double Door Lock Motor Front RH	
	Position SW Front RH	
D21	Door Lock Control SW (LHD 3–Door w/o Jam Protection)	90980–10997
	Door Lock Control SW (w/ Jam Protection)	90980–12166
	Door Lock Control SW (w/o Jam Protection Except LHD 3–Door)	90980–12122
	Power Window Master SW (LHD 3–Door w/o Jam Protection)	90980–10997
	Power Window Master SW (w/ Jam Protection)	90980–12166
	Power Window Master SW (w/o Jam Protection Except LHD 3–Door)	90980–12122
D22	Door Lock Motor Rear LH	90980–12226
	Door Unlock Detection SW Rear LH	
	Double Door Lock Motor Rear LH	
	Position SW Rear LH	
D23	Door Lock Motor Rear RH	
	Door Unlock Detection SW Rear RH	
	Double Door Lock Motor Rear RH	
	Position SW Rear RH	
D24	Diode (Back–Up Light)	90980–11071
D25	Diode (Luggage Compartment Light)	90980–10962
E 1	ECT Solenoid (1GR–FE, 1KD–FTV)	90980–12293
	ECT Solenoid (2TR–FE, 1KZ–TE)	90980–10891
E 2	EGR Valve Position Sensor	90980–11143
E 3	Electronic Driver Unit	90980–11592
E 4	Electronic Driver Unit	90980–11593
E 5	Engine Hood Courtesy SW	90980–10942
E 6	Engine Oil Level Sensor	90980–11235
E 7	Engine Speed Sensor	90980–11250
E 8	ECT Pattern Select SW	90980–11013

G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number
E 9	Engine and ECT ECU (A/T) (1GR–FE, 2TR–FE)	90980–12529
	Engine and ECT ECU (A/T) (1KZ–TE)	90980–11638
	Engine and ECT ECU (A/T) (5L–E)	90980–10765
	Engine ECU (M/T) (1GR–FE, 2TR–FE)	90980–12529
	Engine ECU (M/T) (1KZ–TE)	90980–11638
	Engine ECU (M/T) (5L–E)	90980–10765
E10	Engine and ECT ECU (A/T) (1GR–FE, 2TR–FE)	90980–12525
	Engine and ECT ECU (A/T) (1KZ–TE)	90980–11637
	Engine and ECT ECU (A/T) (5L–E)	90980–11408
	Engine ECU (M/T) (1GR–FE, 2TR–FE)	90980–12525
	Engine ECU (M/T) (1KZ–TE)	90980–11637
	Engine ECU (M/T) (5L–E)	90980–11408
E11	Engine and ECT ECU (A/T) (1GR–FE, 2TR–FE)	90980–12527
	Engine and ECT ECU (A/T) (1KZ–TE)	90980–11476
	Engine and ECT ECU (A/T) (5L–E)	90980–11391
	Engine ECU (M/T) (1GR–FE, 2TR–FE)	90980–12527
	Engine ECU (M/T) (1KZ–TE)	90980–11476
	Engine ECU (M/T) (5L–E)	90980–11391
E12	Engine and ECT ECU (A/T) (1GR–FE, 2TR–FE)	90980–12528
	Engine and ECT ECU (A/T) (1KZ–TE)	90980–11421
	Engine and ECT ECU (A/T) (5L–E)	90980–11390
	Engine ECU (M/T) (1GR–FE, 2TR–FE)	90980–12528
	Engine ECU (M/T) (1KZ–TE)	90980–11421
	Engine ECU (M/T) (5L–E)	90980–11390
E13	Engine and ECT ECU (A/T)	90980–12526
	Engine ECU (M/T)	
E14	Engine ECU	90980–12142
E15	Engine ECU	90980–12146
E16	Engine ECU	90980–12528
E17	Engine ECU	90980–12527
E18	ECT ECU	90980–12151
E19	ECT ECU	90980–12149
E20	ECT ECU	90980–12150
F 1	Front Clearance Light LH	90980–10942
	Front Turn Signal Light LH	
F 2	Front Clearance Light RH	
	Front Turn Signal Light RH	
F 3	Front Fog Light LH	90980–11096
F 4	Front Fog Light RH	
F 5	Front Side Turn Signal Light LH	90980–11162
F 6	Front Side Turn Signal Light RH	
F 7	Front Wiper Motor	90980–11599
F 8	Fuel Heater	90980–10928
F10	Fuel Sedimentary SW	90980–11003

Code	Part Name	Part Number
F11	Fuel Temp. Sensor	90980–10737
F12	Front Blower Motor	90980–10385
F13	Front Passenger's Seat Belt Warning Light	90980–11296
F14	Front Door Speaker LH	90980–10935
F15	Front Door Speaker RH	
F16	Front Door Squawker LH	90980–10860
F17	Front Door Squawker RH	
F18	Front Door Tweeter Speaker LH	90980–11013
F19	Front Door Tweeter Speaker RH	
F20	Fuel Pump	90980–11038
F21	Fuel Pump and Sender (Gasoline)	90980–11077
	Fuel Sender (Diesel)	
F22	Fuel Sender	82890–32030
F23	Fuel Sender (Sub)	90980–11038
F24	Fuel Sender (Sub)	82890–32030
F25	Fuel Pump Resistor	90980–11156
F26	Fuel Pressure Sensor	90980–11194
G 1	Glow Plug (1KD–FTV, 1KZ–TE)	99141–13004
	Glow Plug (5L–E)	90980–09318
G 2	Gateway ECU	90980–11911
G 3	Glove Box Light	90980–11148
G 4	Glove Box Light SW	90980–11098
H 1	Headlight Beam Level Control Actuator LH	90980–11016
H 2	Headlight Beam Level Control Actuator RH	
H 3	Headlight Cleaner Motor	90980–11410
H 4	Headlight Cleaner Relay	90980–10939
H 5	Headlight LH	90980–11314
H 6	Headlight RH	
H 8	Horn (High)	90980–10619
H 9	Horn (Low)	
H10	Hazard SW	90980–10789
H11	Headlight Beam Level Control SW	90980–10996
H12	Heater Control SW (w/ Navigation System)	90980–11915
	Heater Control SW (w/o Navigation System)	90980–11923
H13	Height Control and Suspension SW	90980–11923
H14	Height Control Compressor	90980–10990
H15	Height Control Exhaust Valve	90980–11156
H17	Height Control Sensor Rear LH	90980–11016
H18	Height Control Sensor Rear RH	
H19	High Mounted Stop Light	90980–11003
H20	Heated Oxygen Sensor (Bank 1 Sensor 2)	90980–11028
H21	Heated Oxygen Sensor (Bank 2 Sensor 2)	
I 1	Ignition Coil and Igniter No.1	90980–11885
I 2	Ignition Coil and Igniter No.2	
I 3	Ignition Coil and Igniter No.3	
I 4	Ignition Coil and Igniter No.4	

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number
I 5	Injection Pump	90980–11028
I 6	Injector No.1	90980–11875
I 7	Injector No.2	
I 8	Injector No.3	
I 9	Injector No.4	
I10	Intake Air Temp. Sensor (1KD–FTV, 1KZ–TE)	90980–11025
	Intake Air Temp. Sensor (5L–E)	90980–11163
I12	Idle–Up SW	90980–10933
I13	Ignition Key Cylinder Light	90980–12092
	Transponder Key Amplifier	
I14	Ignition SW	90980–11615
I15	Interior Light	90980–12321
I16	Ignition Coil and Igniter No.5	90980–11885
I17	Ignition Coil and Igniter No.6	
I18	Injector No.5	90980–11875
I19	Injector No.6	
J 1	Junction Connector	90980–11915
J 2	Junction Connector	90980–11661
J 3	Junction Connector	
J 4	Junction Connector	90980–10891
J 5	Junction Connector	
J 6	Junction Connector	
J 7	Junction Connector	90980–11661
J 8	Junction Connector	
J 9	Junction Connector	90980–10803
J10	Junction Connector	90980–11542
J11	Junction Connector	90980–11915
J12	Junction Connector	90980–10976
J13	Junction Connector	90980–11542
J14	Junction Connector	90980–11915
J15	Junction Connector	90980–10976
J16	Junction Connector	90980–11542
J17	Junction Connector	90980–11915
J18	Junction Connector	
J19	Junction Connector	
J20	Junction Connector	
J21	Junction Connector	
J22	Junction Connector	90980–11542
J23	Junction Connector (LHD)	90980–11915
	Junction Connector (RHD)	90980–11542
J24	Junction Connector	90980–10976
J25	Junction Connector	90980–11915
J26	Junction Connector	90980–11542
J27	Junction Connector	
J28	Junction Connector	

Code	Part Name	Part Number
J29	Junction Connector	90980–11238
J30	Junction Connector	
J31	Junction Connector	90980–11686
J33	Junction Connector	90980–11542
J34	Junction Connector	
J35	Junction Connector	90980–11661
J36	Junction Connector	
J37	Junction Connector	
J38	Junction Connector	
J39	Junction Connector	90980–11542
J40	Junction Connector	90980–12355
J41	Junction Connector	
J42	Junction Connector	
J43	Junction Connector	
J44	Junction Connector	
J45	Junction Connector	90980–10871
K 1	Knock Sensor (Bank 1)	90980–11875
K 2	Key Interlock Solenoid	90980–10795
	Unlock Warning SW	
K 3	Knock Sensor (Bank 1)	90980–11875
K 4	Knock Sensor (Bank 2)	
L 1	License Plate Light	90980–11002
L 2	License Plate Light LH	90980–11148
L 3	License Plate Light RH	
L 4	Luggage Compartment Light	90980–12321
L 5	Low Pressure Tank Valve	90980–11156
M 1	Magnetic Spill Valve	90980–11284
M 2	Master Cylinder Pressure Sensor	90980–11451
M 3	Mirror Heater SW	90980–10789
M 4	Multi–Display	90980–12203
M 5	Multi–Display	90980–12410
M 7	Mirror Heater LH	90980–12059
	Remote Control Mirror LH	
M 8	Mirror Heater RH	
	Remote Control Mirror RH	
M 9	Moon Roof Control ECU and Motor	90980–10997
N 1	Neutral Start SW (1GR–FE, 2TR–FE, 1KD–FTV)	90980–12362
	Neutral Start SW (1KZ–TE)	90980–11784
N 2	Noise Filter	90980–10843
N 3	Navigation ECU	90980–11923
N 4	Navigation ECU	90980–11973
N 5	Noise Filter (Condenser Fan)	90980–10843
O 1	Oil Pressure SW (Except 5L–E)	90980–11363
	Oil Pressure SW (5L–E)	90980–10703
O 2	Option Connector (Keyless Buzzer)	90980–11051

G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number
O 3	Option Connector (Door Control Receiver)	90980–10803
O 4	Overhead J/B	90980–12155
P 1	Power Steering Oil Pressure SW	90980–11428
P 2	Pressure SW	90980–11149
P 3	Pressure SW	90980–10943
P 4	Parking Brake SW	90980–10871
P 5	Power Outlet (Front)	90980–10760
P 6	PTC Heater	90980–11385
P 7	PTC Heater	90980–10958
P 8	Personal Light	90980–11923
P 9	Power Outlet (Rear)	90980–10760
P10	Power Window Control SW Front LH (w/ Jam Protection)	90980–11947
	Power Window Control SW Front LH (w/o Jam Protection)	90980–10789
P11	Power Window Control SW Front RH (w/ Jam Protection)	90980–11947
	Power Window Control SW Front RH (w/o Jam Protection)	90980–10789
P12	Power Window Control SW Rear LH (w/ Jam Protection)	90980–11947
	Power Window Control SW Rear LH (w/o Jam Protection)	90980–10789
P13	Power Window Control SW Rear RH (w/ Jam Protection)	90980–11947
	Power Window Control SW Rear RH (w/o Jam Protection)	90980–10789
P14	Power Window Motor Front LH	90980–10797
P15	Power Window Motor Front RH	
P16	Power Window Motor Rear LH	
P17	Power Window Motor Rear RH	
P18	Pretensioner LH	90980–12253
P19	Pretensioner RH	
P20	Power Seat Control SW (Driver's Seat Lumbar Support Control)	90980–10789
P21	Power Seat Control SW (Driver's Seat)	90980–10997
P22	Power Seat Control SW (Front Passenger's Seat)	
P23	Power Seat Motor (Driver's Seat Front Vertical Control)	90980–10825
P24	Power Seat Motor (Driver's Seat Lifter Control)	
P25	Power Seat Motor (Driver's Seat Lumbar Support Control)	
P26	Power Seat Motor (Driver's Seat Reclining Control)	
P27	Power Seat Motor (Driver's Seat Slide Control)	
P28	Power Seat Motor (Front Passenger's Seat Reclining Control)	
P29	Power Seat Motor (Front Passenger's Seat Slide Control)	

Code	Part Name	Part Number
P30	Pressure Discharge Valve	90980–11153
R 1	Radio and Player	90980–10997
R 2	Radio and Player	90980–12183
R 3	Radio and Player	90980–12038
R 4	Radio and Player	90980–10996
R 5	Radio and Player	90980–12259
R 6	Rear Blower SW	90980–11118
R 7	Rear Cooler Control SW (Automatic A/C)	90980–11923
	Rear Cooler Control SW (Manual A/C)	90980–12012
R 8	Rear Diff. Lock Control ECU	90980–10801
R 9	Rear Diff. Lock SW	90980–10631
R10	Rear Fog Light SW	90980–12113
R11	Remote Control Mirror SW	90980–11657
R12	Rheostat	90980–11989
R13	Rear Combination Light LH	90980–10797
R14	Rear Combination Light LH	90980–11292
R15	Rear Combination Light RH	90980–10797
R16	Rear Combination Light RH	90980–11292
R17	Rear Cooler Amplifier	90980–10801
R18	Rear Cooler Blower Motor	90980–10214
R19	Rear Cooler Blower Resistor	90980–10976
R20	Rear Cooler Magnetic Valve	90980–10860
R21	Rear Cooler Power Transistor	90980–10171
R22	Rear Cooler Relay	90980–10713
R23	Rear Cooler Thermistor	90980–10825
R24	Rear Diff. Lock Motor	90980–11194
R25	Rear Door Speaker LH	90980–10935
R26	Rear Door Speaker RH	
R27	Rear Fog Light LH	90980–11002
R28	Rear Fog Light RH	
R29	Rear Height Control Valve	90980–11143
R30	Rear Speaker LH	90980–10935
R31	Rear Speaker RH	
R32	Rear Window Defogger	90980–10870
R33	Rear Wiper Motor (Spare Tire–Back Door Mounted)	90980–10908
	Rear Wiper Motor (Spare Tire–Under Floor Mounted)	90980–10795
S 1	Skid Control ECU with Actuator (w/ VSC)	90980–12297
	Skid Control ECU with Actuator (w/o VSC)	90980–12020
S 2	Speed Sensor (Combination Meter)	90980–11143
S 3	Speed Sensor (ECT)	90980–11156
S 4	Starter (1GR–FE, 2TR–FE)	90980–09463
	Starter (1KD–FTV, 1KZ–TE, 5L–E)	90980–09529

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number
S 5	Starter (1GR–FE, 2TR–FE)	90980–11400
	Starter (1KD–FTV, 5L–E)	90980–11184
	Starter (1KZ–TE)	
S 6	Suction Control Valve	90980–11285
S 8	Seat Heater SW Front LH	90980–10964
S 9	Seat Heater SW Front RH	90980–10933
S10	Shift Lock Control ECU	90980–12183
S11	Skid Control ECU	90980–11638
S12	Skid Control ECU	90980–11476
S13	Skid Control ECU	90980–11637
S14	Skid Control ECU	90980–11935
S15	Steering Sensor	90980–12155
S16	Stereo Component Amplifier	90980–10848
S17	Stereo Component Amplifier	90980–11877
S18	Stop Light SW	90980–11118
S19	Suspension Control ECU	90980–12150
S20	Suspension Control ECU	90980–12149
S21	Suspension Control ECU	90980–12151
S22	Side Airbag Sensor Front LH	90980–12225
S23	Side Airbag Sensor Front RH	
S24	Side Airbag Sensor Rear LH	
S25	Side Airbag Sensor Rear RH	
S26	Seat Heater (Driver's Seat)	90980–10797
S27	Seat Heater (Front Passenger's Seat)	
S28	Side Airbag Squib LH	90980–11864
S29	Side Airbag Squib RH	
S30	Skid Control ECU with Actuator	90980–12294
S31	Swirl Control Valve	90980–11156
T 1	Theft Deterrent Horn	90980–10619
T 2	Throttle Control Motor	90980–11144
T 3	Throttle Open SW	90980–11156
T 5	Timing Control Valve	90980–11285
T 6	Transfer Actuator	90980–11664
T 7	Turbo Pressure Sensor	90980–10845
T 8	Theft Deterrent ECU	90980–12169

Code	Part Name	Part Number
T 9	Transponder Key Computer	90980–11911
T10	Turn Signal Flasher	90980–10799
T11	Theft Deterrent Siren (LHD, RHD 3–Door)	90980–11349
	Theft Deterrent Siren (RHD 5–Door)	90980–10799
T12	Trailer Socket	90980–10797
T14	Throttle Control Motor	90980–11858
	Throttle Position Sensor	
T15	Turbine Speed Sensor	90980–11156
T16	Turbo Motor Driver	90980–10801
V 1	Vacuum Sensor	90980–10845
V 2	Variable Resistor	90980–10902
V 3	Viscous Heater Magnetic Clutch	90980–11271
V 5	VRV (EGR)	90980–11162
V 6	VSC Check Connector	90980–11609
V 7	VSC Check Connector	90980–11612
V 8	VSV (EGR Cut) (1KD–FTV)	90980–11156
	VSV (EGR Cut) (1KZ–TE)	90980–11149
V 9	VSV (Engine Mount)	90980–11149
V10	VSV (EVAP)	90980–11156
V12	Viscous Heater Amplifier	90980–11913
V13	VSC Warning Buzzer	90980–10906
V14	Vanity Light LH	90980–12322
V15	Vanity Light RH	
V17	VSV (ACIS)	90980–11149
V18	VVT Sensor LH	90980–12353
V19	VVT Sensor RH	
W 1	Washer Motor	90980–11028
W 2	Water Temp. Sender	90980–11428
W 3	Water Temp. Sensor (1GR–FE, 2TR–FE)	90980–10735
	Water Temp. Sensor (1KD–FTV)	
	Water Temp. Sensor (1KZ–TE, 5L–E)	90980–10737
W 4	Water Temp. Sensor (A/C)	90980–10860
W 5	Woofer Speaker	90980–10795
Y 1	Yaw Rate Sensor (Except 1KZ–TE)	90980–11904
	Yaw Rate Sensor (1KZ–TE)	90980–12080