

# MANUAL TRANSMISSION/TRANSAXLE

022I1–01

## PREPARATION

### SST

| | | | |
|---|---|---|---|
|  | 09223–00010 | Cover & Seal Replacer | TRANSFER ADAPTER OIL SEAL(1GR–FE) |
|  | 09308–00010 | Oil Seal Puller | TRANSFER ADAPTER OIL SEAL(1GR–FE) |

### Equipment

| | |
|---|---|
| Torque wrench | |

### Lubricant

| Item | Capacity | Classification |
|---|---|---|
| Manual transmission oil | 2.2 liters (2.3 US qts, 1.9 lmp. qts) | API GL–4 or GL–5<br>SAE 75W–90 |