054JF–03

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See page
Engine does not crank (Does not start)	1. Cranking holding function circuit 2. Starter 3. Starter relay	05–227 19–1 19–1
No initial combustion (Does not start)	1. ECM power source circuit 2. Fuel pump control circuit 3. ECM	05–215 05–235 01–35
No complete combustion (Does not start)	1. Fuel pump control circuit	05–235
Engine cranks normally (Difficult to start)	1. Starter signal circuit 2. Fuel pump control circuit 3. Compression	05–155 05–235 14–1
Cold engine (Difficult to start)	1. Starter signal circuit 2. Fuel pump control circuit	05–155 05–235
Hot engine (Difficult to start)	1. Starter signal circuit 2. Fuel pump control circuit	05–155 05–235
High engine idle speed (Poor idling)	1. A/C signal circuit (Compressor circuit) 2. ECM power source circuit	05–363 05–215
Low engine idle speed (Poor idling)	1. A/C signal circuit (Compressor circuit) 2. Fuel pump control circuit	05–363 05–235
Rough idling (Poor idling)	1. Compression 2. Fuel pump control circuit	14–1 05–235
Hunting (Poor idling)	1. ECM power source circuit 2. Fuel pump control circuit	05–215 05–235
Hesitation/Poor acceleration (Poor driveability)	1. Fuel pump control circuit 2. A/T faulty	05–235 05–299
Surging (Poor driveability)	1. Fuel pump control circuit	05–235
Engine stalls soon after starting	1. Fuel pump control circuit	05–235
Engine stalls during A/C operation	1. A/C signal circuit (Compressor circuit) 2. ECM	05–363 01–35
Unable to refuel/Difficult to refuel	1. ORVR system	–