TEMS & REAR AIR SUSPENSION SYSTEM (1GR–FE)

056J9–03

HOW TO PROCEED WITH TROUBLESHOOTING

1	VEHICLE BROUGHT TO WORKSHOP

2	CUSTOMER PROBLEM ANALYSIS (See Pub. No. RM990E, page 05–579)

3	CHECK AND CLEAR DTCs (See page 05–258)

4	PROBLEM SYMPTOM CONFIRMATION

→ SYMPTOM DOES NOT OCCUR (Go to step 5)

→ SYMPTOM OCCURS (Go to step 6)

5	SYMPTOM SIMULATION (See page 01–25)

6	DTC CHECK (See page 05–258)

→ NORMAL CODE (Go to step 7)

→ MALFUNCTION CODE (Go to step 8)

7	PROBLEM SYMPTOMS TABLE (See page 05–272)

8	DTC CHART (See page 05–267)

9	CIRCUIT INSPECTION (See page 05–274)

10	IDENTIFICATION OF PROBLEM

11	REPAIR

12	CONFIRMATION TEST

END

HINT:
Step 3, 6, 9, 12:
Diagnostic steps permitting the use of the hand–held tester.