DTC B2793 TRANSPONDER CHIP MALFUNCTION

CIRCUIT DESCRIPTION

This DTC is output when trouble is found in a key during the key code registration or the key code is not registered normally. Replace the key when the key code registration is not performed normally and this DTC is detected.

DTC No.	DTC Detection Condition	Trouble Area
B2793	Transponder chip malfunction	• Key

INSPECTION PROCEDURE

1 CHECK DTC

(a) Delete the DTC.
(b) Insert the key into the ignition key cylinder.
(c) Check that no code is output.

OK → **NO PROBLEM**

NG

2 RE–REGISTER KEY

(a) Delete the DTC.
(b) Re–register the key, and check that the engine starts with the key.

OK → **NORMAL**

NG

REPLACE KEY