DTC	P0500/21	VEHICLE SPEED SENSOR "A"

DTC	P0503/23	VEHICLE SPEED SENSOR "A" INTERMITTENT/ERRATIC/HIGH

CIRCUIT DESCRIPTION

See page 05–142.

DTC No.	DTC Detecting Condition	Trouble Area
P0500/21	The malfunction code is output when the vehicle speed signal from the vehicle speed sensor is open for 140 ms or more while cruise control is in operation.	• Combination meter assy • Vehicle speed sensor • Vehicle speed sensor circuit • ECM
P0503/23	Momentary interruption and noise malfunction codes are output when a rapid change of vehicle speed occurs while cruise control is in operation.	

WIRING DIAGRAM

See page 05–142.

INSPECTION PROCEDURE

See page 05–142.