EFI SYSTEM (1GR–FE)(From August, 2004)

PRECAUTION

05N2Y–01

NOTICE:

Perform the RESET MEMORY (AT initialization) operation after replacing the automatic transaxle assembly, engine assembly or ECM (see page 05–1026).

HINT:

RESET MEMORY can not be completed by only disconnection the battery terminal.