05N2Z–01

CHECK FOR INTERMITTENT PROBLEMS

HINT:

Intelligent Tester II only:

Inspect the vehicle's ECM using check mode. Intermittent problems are easier to detect when the Intelligent Tester II is in check mode. In check mode, the Intelligent Tester II uses 1 trip detection logic, which has a higher sensitivity to malfunctions than normal mode (default), which uses 2 trip detection logic.

(a) Clear the DTCs (see page 05–209).

(b) Set the check mode (see page 05–210).

(c) Perform a simulation test (see page 01–26).

(d) Check the connector and terminal (see page 01–36).

(e) Handle the connector (see page 01–36).