05N34–01

FAIL–SAFE CHART

If any of the following codes are recorded, the ECM enters the fail–safe mode.

DTC No.	Fail–Safe Operation	Fail–Safe Deactivation Conditions
P0031 P0032 P0037 P0038 P0051 P0052 P0057 P0058	The heater circuit in which the abnormality is detected is turned off	Ignition switch OFF
P0100 P0102 P0103	Ignition timing is calculated from engine speed and a throttle angle	Returned to normal condition
P0110 P0112 P0113	Intake air temp. is fixed at 20°C (68°F)	Returned to normal condition
P0115 P0117 P0118	Engine coolant temp. is fixed at 80°C (176°F)	Returned to normal condition
P0120 P0122 P0123 P0220 P0222 P0223 P2135	Fuel cut intermittently when idle	Returned to normal condition and ignition switch OFF
P0121	Fuel cut intermittently when idle	Returned to normal condition and ignition switch OFF
P0325 P0327 P0328 P0330 P0332 P0333	Max. timing retardation	Ignition switch OFF
P0351 P0352 P0353 P0354 P0355 P0356	Fuel cut	Returned to normal condition
P2102 P2103	Fuel cut intermittently when idle	Returned to normal condition and ignition switch OFF
P2111 P2112	Fuel cut intermittently when idle	
P2119	Fuel cut intermittently when idle	