DTC	P0604	INTERNAL CONTROL MODULE RANDOM ACCESS MEMORY (RAM) ERROR

DTC	P0606	ECM/PCM PROCESSOR

DTC	P0607	CONTROL MODULE PERFORMANCE

DTC	P0657	ACTUATOR SUPPLY VOLTAGE CIRCUIT/OPEN

CIRCUIT DESCRIPTION

DTC No.	DTC Detection Condition	Trouble Area
P0604 P0606 P0607 P0657	ECM inside error	• ECM

INSPECTION PROCEDURE

HINT:

Read freeze frame data using the Intelligent Tester II. Freeze frame data records the engine conditions when a malfunction is detected. When troubleshooting, freeze frame data can help determine if the vehicle was running or stopped, if the engine was warmed up or not, if the air–fuel ratio was lean or rich, and other data from the time the malfunction occurred.

CHECK AND REPLACE ECM (See page 01–36)