
05M50–02

DTC CHECK/CLEAR

NOTICE:

Intelligent tester II only:


When the diagnosis system is changed from normal mode to check mode, or vice versa, all the DTCs and freeze frame data recorded in normal mode will be erased. Before changing modes, always check and make a note of any DTCs and freeze frame data.



1. CHECK DTC (using intelligent tester II)

(a) Connect the intelligent tester II to the DLC3.


(b) Turn the ignition switch ON and turn the intelligent tester II ON.



(c) Enter the following menus: Powertrain / Engine / DTC.

(d) Check and make a note of DTCs and freeze frame data.


(e) Confirm the details of the DTCs (see page 05–477).




2. CHECK DTC (not using intelligent tester II)

(a) Turn the ignition switch ON.

(b) Using SST, connect between terminals 13 (TC) and 4 (CG) of the DLC3.
SST 09843–18040



(c) Read DTCs by observing the MIL. If any DTC is not detected, the MIL blinks as shown in the illustration.



(d) Example
  (1) DTCs 12 and 31 are detected and the MIL starts displaying the DTCs, as shown on the left. The MIL flashing pattern of DTC 12 will be displayed first.
  (2) A 2.5 second pause will occur. This pause will occur between the MIL blinking patterns of each DTC.
  (3) The MIL flashing pattern of DTC 31 will be displayed.
  (4) A 4.5 second pause will occur. This pause will occur when the MIL blinking pattern is the last of a string of multiple DTCs.
  (5) The MIL will repeat the display of the string of DTCs again.


(e) Check the details of the malfunction using the DTC chart on page 05–477.

(f) After completing the check, disconnect terminals 13 (TC) and 4 (CG) and turn off the display.

HINT:

If 2 or more DTCs are detected, the MIL will display the smaller number DTC first.

(g) Confirm the details of the DTCs (see page 05–477).




3. CLEAR DTCS AND FREEZE FRAME DATA (using intelligent tester II)

(a) Connect the intelligent tester II to the DLC3.

(b) Turn the ignition switch ON (do not start the engine) and turn the intelligent tester II ON.

(c) Enter the following menus: Powertrain / Engine / DTC / Clear.

(d) Erase DTCs and freeze frame data by pressing YES on the tester.



4. CLEAR DTCS AND FREEZE FRAME DATA (without using intelligent tester II)

(a) Perform either one of the following operations.
  (1) Disconnect the cable from the battery negative (–) terminal for more than 1 minute.
  (2) Remove the EFI fuse from the engine room J/B located inside the engine compartment for more than 1 minute.