# DTC C1201/51 ENGINE CONTROL SYSTEM MALFUNCTION

## CIRCUIT DESCRIPTION

If trouble occurs in the engine control system, the ECM transmits the abnormality to the skid control ECU. The skid control ECU set this DTC and the skid control ECU prohibits TRC and VSC control.

| DTC No. | DTC Detection Condition | Trouble Area |
|---|---|---|
| C1201/51 | Malfunction signal is received from ECM | Engine control system |

## INSPECTION PROCEDURE

| 1 | CHECK DTC (FOR ENGINE CONTROL SYSTEM) |
|---|---|

(a) Check if the normal system code is recorded for the SFI or ECD system (see page 05–209, 05–466).

**Result:**

| | |
|---|---|
| Normal system code | A |
| Trouble code | B |

B → **REPAIR ENGINE CONTROL SYSTEM ACCORDING TO OUTPUT CODE (SEE PAGE 05–220, 05–477)**

A →

**REPLACE ECM (SEE PUB. NO. RM1017E, PAGE 10–11) (SEE PUB. NO. RM990E, PAGE 10–34)**