DTC C1223/43 MALFUNCTION IN ABS CONTROL SYSTEM

CIRCUIT DESCRIPTION

DTC No.	DTC Detection Condition	Trouble Area
C1223/43	ABS control system is abnormal	ABS control system

HINT:

- This DTC is output when the VSC system detects a malfunction in the ABS system.
- When DTC C1223/43 is memorized, there is no malfunction in the skid control ECU.

INSPECTION PROCEDURE

1	CHECK DTC (FOR ABS SYSTEM)

(a) Clear the DTCs (see page 05–766).

(b) Check if DTCs are recorded.

Result:

DTC is output	A
DTC is not output	B

B → END

A → REPAIR CIRCUIT INDICATED BY OUTPUT CODE (SEE PAGE 05–776)