BLACK SCREEN (NO IMAGE APPEARS ON NAVIGATION AND AUDIO SCREEN)

INSPECTION PROCEDURE

1	CHECK DISPLAY SETTING

(a) Check that the display is not in ”Screen OFF” mode.
OK: The display setting is not in ”Screen OFF” mode.

NG → **CHANGE SCREEN TO ”SCREEN ON” MODE**

OK

2	CHECK IMAGE QUALITY SETTING

(a) Check if screen color quality can be set.
OK: Switching is possible.

OK → **PRESS PANEL SWITCH ”DISPLAY” AND SET SCREEN COLOR QUALITY TO NORMAL**

NG

3	CHECK CABIN

(a) Check if condensation is likely to occur, or the temperature is high or low (extremely cold) in the cabin.
HINT:
This problem occurs when the cabin is humid and the temperature rapidly changes. This condition may produce condensation, resulting in a short circuit.
OK: The above condition is not observed.

NG → **SET CABIN TEMPERATURE TO APPROPRIATE DEGREES (20 TO 30°C) (68 TO 86°F)**

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE
(SEE PAGE 05–1309)