05G9C–05

DIAGNOSTIC TROUBLE CODE CHART

1. DTC TABLE BY ECU

HINT:

- In the CAN communication system, CAN communication system DTCs can be displayed by the ECU using the intelligent tester II (see page 05–1443).
- If CAN communication system DTCs are output, trouble cannot be determined only by the DTCs. Perform troubleshooting according to ”HOW TO PROCEED WITH TROUBLESHOOTING” (see page 05–1433).

(a) Skid Control ECU

HINT:

DTC communication uses the SIL line.

DTC No.	Detection Item
U0073/94	Control Module Communication Bus Off
U0100/65	Lost Communication With ECM/PCM ”A”
U0123/62	Lost Communication With Yaw Rate Sensor Module
U0124/95	Lost Communication With Lateral Acceleration Sensor Module
U0126/63	Lost Communication With Steering Angle Sensor Module

(b) ECM

HINT:

The ECM is connected to the CAN communication system but CAN communication system DTCs are not output.