CHARGING SYSTEM (2TR–FE)

190LB–03

PRECAUTION

1. **Check that the battery cables are connected to the correct terminals.**
2. **Disconnect the battery cables when the battery is charged quickly.**
3. **Do not perform tests with a high voltage insulation resistance tester.**
4. **Never disconnect the battery while the engine is running.**
5. **Check that the charging cable is connected to terminal B of the generator and the fuse box.**
6. **Do not check the generator with terminal F connected to the other terminal.**