SPEED SENSOR (A750F)

REPLACEMENT

401H5–01



1. REMOVE SPEED SENSOR

(a) Disconnect the connectors.

(b) Remove the 2 bolts and 2 speed sensors.



2. INSTALL SPEED SENSOR

(a) Coat 2 new O–rings with ATF, and install them to the 2 speed sensors.

(b) Install 2 speed sensors with the 2 bolts.
Torque: 5.4 N·m (55 kgf·cm, 48 in.·lbf)

(c) Connect the connectors.