















STEERING COLUMN

PREPARATION






021ZC–01

SST

	09316–60011	Transmission & Transfer Bearing Replacer	STEERING COLUMN ASSY
	(09316–00051)	Replacer ”D”	STEERING COLUMN ASSY
	09921–00010	Spring Tension Tool	STEERING COLUMN ASSY
	09950–40011	Puller B Set	STEERING COLUMN ASSY
	(09951–04010)	Hanger 150	STEERING COLUMN ASSY
	(09952–04010)	Slide Arm	STEERING COLUMN ASSY
	(09953–04020)	Center Bolt 150	STEERING COLUMN ASSY
	(09954–04010)	Arm 25	STEERING COLUMN ASSY
	(09955–04061)	Claw No.6	STEERING COLUMN ASSY
	(09958–04011)	Holder	STEERING COLUMN ASSY
	09950–50013	Puller C Set	STEERING COLUMN ASSY
	(09951–05010)	Hanger 150	STEERING COLUMN ASSY

	(09952–05010)	Slide Arm	STEERING COLUMN ASSY
	(09953–05020)	Center Bolt 150	STEERING COLUMN ASSY
	(09954–05021)	Claw No.2	STEERING COLUMN ASSY
	09950–60010	Replacer Set	STEERING COLUMN ASSY
	(09951–00300)	Replacer 30	STEERING COLUMN ASSY
	(09951–00340)	Replacer 34	STEERING COLUMN ASSY
	09950–70010	Handle Set	STEERING COLUMN ASSY
	(09951–07150)	Handle 150	STEERING COLUMN ASSY
	(09951–07360)	Handle 360	STEERING COLUMN ASSY

Recomended Tools

	09031–00030	Pin Punch	STEERING COLUMN ASSY
	09042–00010	Torx Socket T30	STEERING COLUMN ASSY
	(09043–20060)	Socket Hexagon Wrench 6	STEERING COLUMN ASSY
	09904–00010	Expander Set	STEERING COLUMN ASSY
	(09904–00050)	No. 4 Claw	STEERING COLUMN ASSY

EQUIPMENT

Torque wrench	