TEMS & REAR AIR SUSPENSION SYSTEM

056J9–02

HOW TO PROCEED WITH TROUBLESHOOTING

1	VEHICLE BROUGHT TO WORKSHOP

2	CUSTOMER PROBLEM ANALYSIS (See page 05–579)

3	CHECK AND CLEAR DTCS (See page 05–580)

4	PROBLEM SYMPTOM CONFIRMATION

→ SYMPTOM DOES NOT OCCUR (Go to step 5)

→ SYMPTOM OCCUR (Go to step 6)

5	SYMPTOM SIMULATION (See page 01–36)

6	DTC CHECK (See page 05–580)

→ NORMAL CODE (Go to step 7)

→ MALFUNCTION CODE (Go to step 8)

7	PROBLEM SYMPTOMS TABLE (See page 05–596)

8	DTC CHART (See page 05–589)

9	CIRCUIT INSPECTION (See page 05–598 to 05–666)

10	**IDENTIFICATION OF PROBLEM**

11	**REPAIR**

12	**CONFIRMATION TEST**

END

HINT:
Step 3, 6, 9, 12:
Diagnostic steps permitting the use of the hand–held tester.