05A9A–01

PROBLEM SYMPTOMS TABLE

If a normal code is displayed during the DTC check although the problem still occurs, check the circuits for each problem symptom in the order given in the table below and proceed to the relevant troubleshooting page.

NOTICE:

When replacing skid control ECU, sensor or etc., turn the ignition switch OFF.

Symptom	Suspected Area	See page
ABS does not operate	Only when 1 to 4 are all normal but problem still occurs, replace skid control ECU 1. Check DTC reconfirming that normal code is output 2. IG power source circuit and ground circuit 3. Speed sensor circuit	 05–671 05–701 05–684 05–689
ABS does not operate efficiently	Only when 1 to 5 are all normal but problem still occurs, replace skid control ECU 1. Check DTC reconfirming that normal code is output 2. IG power source circuit and ground circuit 3. Speed sensor circuit 4. Stop light switch circuit	 05–671 05–701 05–684 05–689
ABS warning light is abnormal	1. ABS warning light circuit 2. Skid control ECU	05–718
Brake warning light is abnormal	1. Brake warning light circuit 2. Skid control ECU	05–720
DTC check	Only when 1 and 2 are all normal and problem still occurs, replace skid control ECU 1. ABS warning light circuit 2. Tc terminal circuit	 05–718 05–722
Speed sensor signal check is impossible	1. Ts terminal circuit 2. Skid control ECU	05–724