05AAT–01

PROBLEM SYMPTOMS TABLE

If a normal code is displayed during the DTC check but the problem still occurs, check the circuits for each problem symptom in the order given in the table below and proceed to the relevant troubleshooting page.

NOTICE:

When replacing skid control ECU, sensor or etc., turn the ignition switch OFF.

Symptom	Suspect Area	See page
ABS does not operate BA does not operate EBD does not operate	If the symptoms still occur even after the following circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU. 3. Check the DTC again and make sure that the normal code is output. 4. IG power source circuit 5. Speed sensor circuit If abnormal, check the hydraulic circuit for leakage.	 05–730 05–797 05–754 05–759
ABS does not operate efficiently BA does not operate efficiently EBD does not operate efficiently	If the symptoms still occur even after the following circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU. 1. Check the DTC again and make sure that the normal code is output. 2. Speed sensor circuit 3. Stop light switch circuit If abnormal, check the hydraulic circuit for leakage.	 05–730 05–754 05–759 05–808
ABS warning light abnormal	1. ABS warning light circuit 2. Skid control ECU	05–852 05–840
DTC of ABS check cannot be done	If the symptoms still occur even after the following circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU. 1. Check the DTC again and make sure that the normal code is output. 2. Tc terminal circuit	 05–730 05–867
Sensor signal check cannot be done	1. Ts terminal circuit 2. Skid control ECU	05–870 05–840
TRC does not operate	If the symptoms still occur even after the following circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU. 1. Check the DTC again and make sure that the normal code is output. 2. IG power source circuit 3. Check the hydraulic circuit for leakage. 4. Speed sensor circuit	 05–730 05–797 – 05–754 05–759

Symptom	Suspect Area	See page
VSC does not operate	If the symptoms still occur even after the following circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU. 1. Check the DTC again and make sure that the normal code is output. 2. IG power source circuit 3. Check the hydraulic circuit for leakage. 4. Speed sensor circuit 5. Deceleration sensor circuit 6. Yaw rate sensor circuit 7. Steering sensor circuit	 05–730 05–797 – 05–754 05–759 05–789 05–831 05–777 05–793 05–784
SLIP indicator light abnormal	1. SLIP indicator light circuit 2. Skid control ECU	05–863 05–840
VSC OFF indicator abnormal	If the symptoms still occur even after the following circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU. 1. Check the DTC again and make sure that the normal code is output. 2. Center diff. lock switch circuit	 05–730 05–856
DTC of VSC check cannot be done	If the symptoms still occur even after the following circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU. 1. Check the DTC again and make sure that the normal code is output. 2. Tc terminal circuit	 05–730 05–867
VSC warning light abnormal	If the symptoms still occur even after the following circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU. 1. Check the DTC again and make sure that the normal code is output. 2. VSC warning circuit	 05–730 05–854