05A7Z–01

DIAGNOSTIC TROUBLE CODE CHART

If a DTC is displayed during the DTC check, check the circuit listed in the table below and proceed to the page given.

*1 : – ... MIL does not light /● ... MIL light up

DTC No. (See Page)	Detection Item	Trouble Area	MIL *1	Memory
38 (05–892)	Transmission Fluid Temperature Sensor Circuit Malfunction (ATF Temperature Sensor)	• Open or short in ATF temperature sensor circuit • ATF temperature sensor • ECM	●	○
61 (05–894)	Speed Sensor No. 2 Malfunction (Speed Sensor SP2)	• Open or short in speed sensor SP2 (No. 2 vehicle speed sensor) circuit • Speed sensor SP2 (No. 2 vehicle speed sensor) • ECM	●	○
62 (05–896)	S1 Solenoid Valve Electrical Malfunction (Shift Solenoid Valve S1)	• Open or short in shift solenoid valve S1 circuit • Shift solenoid valve S1 • ECM	●	○
63 (05–896)	S2 Solenoid Valve Electrical Malfunction (Shift Solenoid Valve S2)	• Open or short in shift solenoid valve S2 circuit • Shift solenoid valve S2 • ECM	●	○
64 (05–899)	SL Solenoid Valve Electrical Malfunction (Shift Solenoid Valve SL)	• Open or short in shift solenoid valve SL circuit • Shift solenoid valve SL • ECM	–	○