05A8S–01

DIAGNOSTIC TROUBLE CODE CHART

If a DTC is displayed during the DTC check, check the circuit listed in the table below and proceed to the page given.

*1 : – ... MIL does not light /● ... MIL light up

DTC No. (See Page)	Detection Item	Trouble Area	MIL *1	Memory
P0710/38 (05–939)	Transmission Fluid Temperature Sensor "A" Circuit (ATF Temperature Sensor)	• Open or short in ATF temperature sensor circuit • ATF temperature sensor • ECM	●	○
P0722/61 (05–941)	Output Speed Sensor Circuit No Signal (Speed Sensor SP2)	• Open or short in speed sensor SP2 (No. 2 vehicle speed sensor) circuit • Speed sensor SP2 (No. 2 vehicle speed sensor) • ECM	●	○
P0743/64 (05–943)	Torque Converter Clutch Circuit Electrical (Shift Solenoid Valve SL)	• Open or short in shift solenoid valve SL circuit • Shift solenoid valve SL • ECM	–	○
P0753/62 (05–945)	Shift Solenoid "A" Electrical (Shift Solenoid Valve S1)	• Open or short in shift solenoid valve S1 circuit • Shift solenoid valve S1 • ECM	●	○
P0758/63 (05–945)	Shift Solenoid "B" Electrical (Shift Solenoid Valve S2)	• Open or short in shift solenoid valve S2 circuit • Shift solenoid valve S2 • ECM	●	○