05A9J–01

DIAGNOSTIC TROUBLE CODE CHART

If a DTC is displayed during the DTC check, check the circuit listed in the table below and proceed to the page given.

*1 : – ... MIL does not light /● ... MIL light up

DTC No. (See Page)	Detection Item	Trouble Area	MIL *1	Memory
38(1) (05–989)	Transmission Fluid Temperature Sensor Circuit Malfunction (ATF Temperature Sensor)	• Open or short in ATF temperature sensor circuit • ATF temperature sensor • ECM	●	○
51 (05–991)	Stop Light Switch Circuit Malfunction	• Open or short in stop light switch circuit • Stop lamp switch assy • ECM	–	○
61(2) (05–993)	Speed Sensor No. 2 Malfunction (Speed Sensor SP2)	• Open or short in speed sensor SP2 (No. 2 vehicle speed sensor) circuit • Speed sensor SP2 (No. 2 vehicle speed sensor) • ECM	●	○
62(1) (05–996)	Shift Solenoid ”A” Electrical (Shift Solenoid Valve S1)	• Open or short in shift solenoid valve S1 circuit • Shift solenoid valve S1 • ECM	●	○
63(2) (05–996)	Shift Solenoid ”B” Electrical (Shift Solenoid Valve S2)	• Open or short in shift solenoid valve S2 circuit • Shift solenoid valve S2 • ECM	●	○
64(4) (05–999)	Shift Solenoid ”E” Electrical (Shift Solenoid Valve SL)	• Open or short in shift solenoid valve SL circuit • Shift solenoid valve SL • ECM	–	○
77(1) (05–1002)	Linear Solenoid for Line Pressure Control Circuit Malfunction (Shift Solenoid Valve SLT)	• Open or short in shift solenoid valve SLT circuit • Shift solenoid valve SLT • ECM	–	○