050YH–13

PROBLEM SYMPTOMS TABLE

HINT:

Proceed with troubleshooting of each circuit in the table below.

Symptom	Suspect Area	See page
• When the ignition switch in ON position, the SRS warning light sometimes lights up after approx. 6 seconds have elapsed.	• SRS warning light circuit malfunction (Always lights up, when ignition switch is ACC or LOCK position).	05–1329
• SRS warning light is always lit up even when ignition switch is in the LOCK position.		
• With the ignition switch in ON position, the SRS warning light does not light up.	• SRS warning light circuit malfunction (Does not light up, when ignition switch is turned to ON).	05–1332
• DTC is not displayed.	• TC Terminal circuit	05–1334
• SRS warning light is always lit up at the time of DTC check procedure.		
• DTC is displayed without TC and CG terminal connection.		