LIGHTING SYSTEM

HOW TO PROCEED WITH TROUBLESHOOTING

05A56–01

1	VEHICLE BROUGHT TO WORK SHOP

2	CUSTOMER PROBLEM ANALYSIS (See page 05–1337)

3	CHECK BODY MULTIPLEX COMMUNICATION SYSTEM (See page 05–1822)

(a) Check that the DTC is output.

	DTC IS OUTPUT (PROCEED TO ”BODY MULTIPLEX COMMUNICATION SYSTEM”)
	DTC IS NOT OUTPUT (GO TO STEP 4)

4	PROBLEM SYMPTOMS TABLE (See page 05–1346)

5	TERMINALS OF ECU (See page 05–1343)

6	CIRCUIT INSPECTION (See Page 05–1349 – 05–1396)

7	IDENTIFICATION OF PROBLEM

8	REPAIR OR REPLACE

9	CONFIRMATION TEST

END