0549M–09

PROBLEM SYMPTOMS TABLE

Symptom	Suspect Area	See page
Pressing power switch does not start system.	1. Radio receiver assy power source circuit 2. Radio receiver assy	05–1424 –
Turning on light switch does not come on night time illumination of radio receiver.	1. Radio receiver assy ILL terminal circuit 2. Radio receiver assy	05–1426 –
No sound is heard from speaker in all modes.	1. Speaker circuit 2. Stereo component amplifier assy 3. Radio receiver assy power source circuit 4. Radio receiver assy	05–1428 – 05–1428 –
Sound quality is bad in all modes. (Volume is too low)	1. Speaker circuit 2. Stereo component amplifier assy 3. Radio receiver assy power source circuit 4. Radio receiver assy	05–1433 – 05–1433 –
Only front speaker (driver side) is not heard *1	1. Stereo component amplifier assy 2. Navigation ECU 3. Speaker circuit	– – 05–1473
Radio broadcast cannot be received. (Bad reception)	1. Antenna circuit 2. Radio receiver assy	05–1444 –
Cassette tape cannot be inserted or played.	1. Cassette tape 2. Radio receiver assy power source circuit 3. Radio receiver assy	– 05–1446 –
Cassette tape cannot be ejected.	1. Cassette tape 2. Radio receiver assy power source circuit 3. Radio receiver assy	– 05–1449 –
Sound quality is bad only when playing tape.	1. Cassette tape 2. Radio receiver assy 3. Stereo component amplifier assy	 05–1452 05–1452
Tape is tangled due to incorrect tape speed or auto–reverse malfunction.	1. Cassette tape 2. Radio receiver assy	 05–1453
CD cannot be inserted or is ejected right after insertion.	1. CD 2. Radio receiver assy power source circuit 3. Radio receiver assy	– 05–1454 –
Although system is powered, CD cannot be played.	1. CD 2. Radio receiver assy power source circuit 3. Radio receiver assy	– 05–1457 –
CD cannot be taken out.	1. CD 2. Radio receiver assy power source circuit 3. Radio receiver assy	– 05–1461 –
Sound quality is bad only when CD is played.(Volume is too low)	1. CD 2. Stereo component amplifier assy	– 05–1464
CD sound skips.	1. CD 2. Radio installation	– 05–1465
Noise occurs.	–	05–1467
Disc player changer screen is not displayed (Both sound and screen are not switched)	1. Disc player changer 2. Radio receiver assy	05–1468 05–1468
Only disc player changer has bad sound (sound is low)	1. CD 2. Disc player changer 3. Radio receiver assy	– 05–1470 05–1470

*1: w/ Navigation Models