0561F–03

PROBLEM SYMPTOMS TABLE

Flow chart No.	Symptom	See page
1	Black screen (Nothing displayed)	05–1544
2	Panel switch does not function.	05–1511
3	No navigation screen displayed when ”MAP/VOICE” ”MENU” or ”DEST” switch pressed (Screen cannot be switched).	05–1512
4	Navigation screen is not stabilized (Synchronous error).	05–1515
5	Color on navigation screen is unusual (RGB signal error)	05–1519
6	Black screen appears when ”MENU”, ”MAP/VOICE” or ”DEST” switch pressed.	05–1524
7	Map disc cannot be inserted.	05–1528
8	Map screen displayed does not appear (Disc caution screen does not change).	05–1530
9	Map is displayed in white or blue screen (Switched and vehicle position mark are displayed).	05–1531
10	Touch switch does not function (Navigation screen only)	05–1532
11	Vehicle position is deviated from correct point badly.	05–1533
12	GPS mark does not appear	05–1535
13	No voice navigation	05–1536
14	Vehicle position mark rotates arbitrarily (Map rotates arbitrarily)	05–1539
15	Driving directions opposite to moving direction of vehicle position mark	05–1542

EXAMPLES OF MISUNDERSTANDING SYMPTOMS AS MALFUNCTIONS

Condition	Cause	Procedure to recover
Screen displays ”AUDIO OFF”, even when ”PWR/VOL” switch is turned off.	”PWR/VOL” switch turns the audio off, but not the screen. To turn off the screen, ”SCREEN OFF” switch must be pressed.	Press ”DISPLAY” switch → Press ”SCREEN OFF” switch on screen
The screen is too dark or too bright, when the screen is changed between navigation and audio.	The contrast set up of the screen between navigation and audio is different. The contrast needs to be set up for each of the navigation and audio screen.	*Navigation: Press ”DISPLAY” and adjust by ”BRIGHTNESS” switch. *AUDIO: Press ”DISPLAY” and adjust by ”CONTRAST” switch.
Present position is not displayed even when ”NAVI” switch is pressed.	Pressing ”NAVI” switch displays the previous screen. For present position, ”MAP/VOICE” switch must be pressed.	Press ”NAVI” switch → Press ”MAP/VOICE” switch.
Even when pressing the panel switch, it doesn’t function.	*Since this switch is pressure sensitive type, press the switch securely. *The panel switch tone–down does not work even if it is pressed.	Press the panel switch securely, if the pressure is weak or time is insufficient, the switch does not function.