PANEL SWITCH DOES NOT FUNCTION

INSPECTION PROCEDURE

1	CHECK SWITCH

(a) Check the switch
  (1) Check that the switch is not pressed double by the foreign objects near the multi–display (CRT display) display switch.
  Standard: No foreign objects

NG → **REMOVE FOREIGN OBJECT**

OK

2	DISPLAY CHECK MODE

(a) Inspect the display
  (1) Boot the diagnosis, preform ”Panel Switch Check” to check that the function is normal.
  Standard: The function is normal

OK → **NORMAL**

NG

CHECK AND REPLACE MULTI–DISPLAY (CRT DISPLAY) DISPLAY