# MAP SCREEN DISPLAYED DOES NOT APPEAR (DISC CAUTION SCREEN DOES NOT CHANGE)

## INSPECTION PROCEDURE

| 1 | TAKE APPROPRIATE MESURES ACCORDING TO CAUTION SCREEN |
|---|---|

(a) Take appropriate measures according to caution screen.

**CAUTION SCREEN**

| CAUTION MESSAGE | CAUSE | CORRECTIVE ACTION |
|---|---|---|
| Cover is open. Please close disc cover before using system. | The cover of the map disc slot is open. | Close the cover. |
| No disc detected. Insert map disc. | No map disc is inserted. | Insert a proper map disc. |
| No disc detected. Insert map disc. Check flaw or dirt on disc. | Cannot read correctly due to flaw or dirt. | Insert a correct map disc. |
| Disc read error.<br>Check disc. | Something other than map disc i s inserted. | Insert a correct map disc. |
| Disc read error due to hight temperature. | Pick–up part of the player is heated to a high temperature. | Stop the vehicle at a shaded cool place and turn the ignition switch OFF.<br>When confirming that the temperature of the navigation ECU has been lowered, turn the ignition switch ON. |
| Disc read error. Consult dealer/shop. | Player cannot read map disc temporarily. | Turn the IG switch from OFF to ON. (*1) |

*1: If the same ”CAUTION MESSAGE” is displayed again even after turning the ignition switch to ON, replace the navigation ECU.

**STANDARD: Correctly functions.**

**OK** → **NORMAL**

**NG**

| 2 | REPLACE DISC PLAYER DISC |
|---|---|

**OK** → **REPLACE DISC PLAYER DISC**

**NG**

**CHECK AND REPLACE NAVIGATION ECU**