MAP IS DISPLAYED IN WHITE OR BLUE SCREEN (SWITCHED AND VEHICLE POSITION MARK ARE DISPLAYED)

INSPECTION PROCEDURE

1	CHECK SETTING

(a) Check the settings.
(1) Check that the map display is normal when setting up the scale of the map widest area.
STANDARD: Map display is normal

OK > NORMAL

NG

2	CHECK AND OPERATE AGAIN

(a) Clean the map disc.
(1) After wiping the map disc in the circumference direction with a soft cloth, insert it again.

OK > NORMAL

NG

3	CHECK AND REPLACE DISC PLAYER DISC

OK > REPLACE DISC PLAYER DISC

NG

CHECK AND REPLACE NAVIGATION ECU