POWER WINDOW CONTROL SYSTEM (W/ JAM PROTECTION)

HOW TO PROCEED WITH TROUBLESHOOTING

05ADU–01

HINT:

Troubleshoot in accordance with the procedures on the following pages.

1	VEHICLE BROUGHT TO WORKSHOP

2	CUSTOMER PROBLEM ANALYSIS CHECK AND SYMPTOM CHECK (See page 05–1590)

3	DIAGNOSTIC TROUBLE CODE CHECK (See page 05–1594)

(a) Check for DTCs and make a note of the code that is output.
(b) Delete the DTC.
(c) Check if the DTC is output once again when the problem symptom is simulated based on the noted code.
  (1) With an output of the code, proceed to A.
  (2) Without an output of the code, proceed to B.

A	Go to step 6

B

4	PROBLEM SYMPTOMS TABLE (See page 05–1599)

5	PERFORM TROUBLESHOOTING

(a) Pre–check (See page 05–1591)
(b) Circuit inspection (See page 05–1601 – 05–1646)

6	ADJUST, REPAIR OR REPLACE

7	RESET POWER WINDOW MOTOR

(a) If any of the power window switch illuminations is blinking after the repair, reset the power window for the switch which illumination is blinking.
  (1) Turn the ignition switch ON.
  (2) Open the door glass.
  (3) Pull up the power window switch for fully until the door glass is fully closed.
  (4) Check that the AUTO UP/DOWN function operates completely.

END