05AE8–01

PROBLEM SYMPTOMS TABLE

Symptoms	Suspected Part	See Page
AUTO UP/DOWN function does not operate at driver side (LHD models)	1. Power window regulator motor assy LH (Driver side) 2. Wire harness 3. Power window regulator master switch assy	05–1603
AUTO UP/DOWN function does not operate at driver side (RHD models)	1. Power window regulator motor assy RH (Driver side) 2. Wire harness 3. Power window regulator master switch assy	05–1606
AUTO UP/DOWN function does not operate at passenger side (LHD models)	1. Power window regulator motor assy RH (Passenger side) 2. Wire harness 3. Power window regulator switch assy RH	05–1609
AUTO UP/DOWN function does not operate at passenger side (RHD models)	1. Power window regulator motor assy LH (Passenger side) 2. Wire harness 3. Power window regulator switch assy LH	05–1612
AUTO UP/DOWN function does not operate at rear LH*1	1. Power window regulator motor assy LH (Rear LH) 2. Wire harness 3. Power window regulator switch assy rear (Rear LH)	05–1615
AUTO UP/DOWN function does not operate at rear RH*1	1. Power window regulator motor assy RH (Rear RH) 2. Wire harness 3. Power window regulator switch assy rear (Rear RH)	05–1618
Manual UP/DOWN function does not operate at driver side (LHD models)	1. Power window regulator master switch assy 2. Power window regulator motor assy LH (Driver side) 3. Wire harness	05–1621
Manual UP/DOWN function does not operate at driver side (RHD models)	1. Power window regulator master switch assy 2. Power window regulator motor assy RH (Driver side) 3. Wire harness	05–1624
Manual UP/DOWN function does not operate at passenger side (LHD models)	1. Power window regulator switch assy (Passenger side) 2. Power window regulator motor assy RH (Passenger side) 3. Wire harness	05–1627
Manual UP/DOWN function does not operate at passenger side (RHD models)	1. Power window regulator switch assy (Passenger side) 2. Power window regulator motor assy LH (Passenger side) 3. Wire harness	05–1630
Manual UP/DOWN function does not operate at rear LH*1	1. Power window regulator switch assy rear (Rear LH) 2. Power window regulator motor assy LH (Rear LH) 3. Wire harness	05–1633
Manual UP/DOWN function does not operate at rear RH*1	1. Power window regulator switch assy rear (Rear RH side) 2. Power window regulator motor assy RH (Rear RH) 3. Wire harness	05–1636
Remote UP/DOWN function does not operate (LHD models)	1. Power window regulator master switch assy 2. Power window regulator switch assy (Passenger side) 3. Power window regulator switch assy rear (Rear LH) 4. Power window regulator switch assy rear (Rear RH) 5. Wire harness 6. Instrument panel J/B assy (Body ECU)	05–1639

Symptoms	Suspected Part	See Page
Remote UP/DOWN function does not operate (RHD models)	1. Power window regulator master switch assy 2. Power window regulator switch assy (Passenger side) 3. Power window regulator switch assy rear (Rear LH) 4. Power window regulator switch assy rear (Rear RH) 5. Wire harness 6. Instrument panel J/B assy (Body ECU)	05–1646
Door glass goes down during AUTO UP operation	1. Door glass run 2. Door window glass 3. Door window regulator sub–assy	05–1653

HINT:

*1: For 5–door models