WINDOW GLASS GOES DOWN DURING AUTO UP OPERATION

CIRCUIT DISCRIPTION

If the door glass or the power window regulator does not smoothly operate, the jam protection function may operate abnormally, resulting in this symptom.

INSPECTION PROCEDURE

1	RESET POWER WINDOW REGULATOR MOTOR

(a) Turn the ignition switch ON.
(b) Open the door glass.
(c) Pull up the power window switch fully until the door glass is fully closed.
(d) Check that the AUTO UP/DOWN function operates completely.

OK → END

NG

2	CHECK POWER WINDOW REGULATOR W/MOTOR

(a) Remove the door glass (See page 75–12 for front door) (See page 75–24 for rear door).
(b) Operate the power window regulator without the door glass using the power window switch.
(c) Check that the power window regulator operates smoothly.

OK → REPLACE DOOR GLASS RUN

NG

REPLACE DOOR WINDOW REGULATOR