05AFQ–01

DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during the DTC check, check the circuit listed for that code in the table below (Proceed to the page given for that circuit.).

DTC No (See Page)	Detection Item	Trouble Area
B1222 (05–1670)	Door lock switch circuit on driver door	• Power window regulator master switch assy • Instrument panel junction block assy (body ECU) • Wire harness