05AFT–01

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
All doors lock and unlock functions do not operate via master switch or driver side door key cylinder	1. DR/LCK fuse 2. ECU–B fuse 3. Power window regulator master switch assy 4. Front door lock assy LH, RH (Driver side) 5. Instrument panel junction block assy (body ECU) 6. Wire harness	05–1675
Key lock–in prevention function does not work properly (Manual operation and operation interlocked with key are active)	1. Unlock warning switch assy 2. Courtesy lamp switch assy LH, RH (Driver side) 3. Instrument panel junction block assy (body ECU) 4. Wire harness	05–1687
w/ Double lock: Double lock function does not operate properly	1. DR/LCK fuse 2. ECU–B fuse 3. Front door lock assy LH, RH 4. Rear door lock assy LH, RH 5. Double lock control relay 6. Wire harness	05–1692