PROBLEM SYMPTOMS TABLE

054CK–02

Problem Symptom	Suspected Area	See Page
Engine does not start	1. Key	05–1752 05–1753 05–1754 05–1755 05–1759
	2. Transponder key amplifier (Transponder key coil)	05–1755 05–1759
	3. Transponder key ECU assy	05–1755 05–1759
	4. Un–lock warning switch assy	05–1747