DTC B2793 TRANSPONDER CHIP MALFUNCTION

CIRCUIT DESCRIPTION

This DTC is output when a trouble is found in a key during the key code registration, also if the key code is not registered normally, this DTC is output.

DTC No.	DTC Detection Condition	Trouble Area
B2793	Transponder chip malfunction	Key

INSPECTION PROCEDURE

1	CHECK DTC

(a) Delete the DTC.
(b) Insert the key into the ignition key cylinder.
(c) Check that no code is output.

OK → NO PROBLEM

NG

2	RE–REGISTER KEY

(a) Delete the DTC.
(b) Re–register the key, and check that the engine starts with the key.

OK → NORMAL

NG

REPLACE KEY