DTC	B2795	UNMATCHED KEY CODE

DTC	P0513	UNMATCH KEY CODE

CIRCUIT DESCRIPTION

This DTC is output when an unregistered key is inserted.

Transponder key ECU:

DTC No.	DTC Detection Condition	Trouble Area
B2795	Key with different ID code inserted in ignition switch	• Key

ECM:

DTC No.	DTC Detection Condition	Trouble Area
P0513	Key with different ID code inserted in ignition switch	• ECM • Wire harness • Transponder key ECU assy

INSPECTION PROCEDURE

1	DELETE DTC AND INSERT ALL PRESENTLY AVAILABLE KEYS TO CHECK WHETHER ENGINE STARTS OR NOT

(a) Check whether the engine starts, after the re–registration of the key with which the engine does not start.

OK → **NO PROBLEM (BECAUSE OF KEY RE–REGISTRATION)**

NG

REPLACE KEY WITH WHICH ENGINE DOES NOT START