PROBLEM SYMPTOMS TABLE

054CK–04

Problem Symptom	Suspected Area	See Page
Engine does not start	1. Key	05–1780 05–1781 05–1782 05–1783 05–1786
	2. Transponder key amplifier (Transponder key coil)	05–1783 05–1786
	3. Transponder key ECU assy	05–1783 05–1786
	4. Un–lock warning switch assy	05–1775