DTC B2793 TRANSPONDER CHIP MALFUNCTION

CIRCUIT DESCRIPTION

This DTC is output when a trouble is found in a key during the key code registration, also if the key code is not registered normally, this DTC is output.

DTC No.	DTC Detection Condition	Trouble Area
B2793	Transponder chip malfunction	• Key

INSPECTION PROCEDURE

1	CHECK DTC

(a) Delete the DTC.
(b) Insert the key into the ignition key cylinder.
(c) Check that no code is output.

OK → NO PROBLEM

NG

2	RE–REGISTER KEY

(a) Delete the DTC.
(b) Re–register the key, and check that the engine starts with the key.

OK → NORMAL

NG

REPLACE KEY