DTC B2795 UNMATCHED KEY CODE

CIRCUIT DESCRIPTION

This DTC is output when an unregistered key is inserted.

DTC No.	DTC Detection Condition	Trouble Area
B2795	Key with different ID code inserted in ignition switch	• Key

INSPECTION PROCEDURE

1	DELETE DTC AND INSERT ALL PRESENTLY AVAILABLE KEYS TO CHECK WHETHER ENGINE STARTS OR NOT

(a) Check whether the engine starts, after the re–registration of the key with which the engine does not start.

OK → NO PROBLEM (BECAUSE OF KEY RE–REGISTRATION)

NG

REPLACE KEY WITH WHICH ENGINE DOES NOT START