058II–03

PROBLEM SYMPTOMS TABLE

Proceed to the reference page shown in the table below for each malfunction symptom and troubleshoot each circuit.

HINT:

Troubleshooting of the theft deterrent system is based on the premise that the door lock control system and the wireless door lock control system are operating normally. Accordingly, before troubleshooting the theft deterrent system, first make certain that the door lock control system and the wireless door lock control system are operating normally.

Symptom	Suspected Area	See Page
Theft deterrent system cannot be set	1. Security indicator light circuit 2. ECU power source circuit 3. Un–lock warning switch circuit 4. Door key lock and unlock switch 5. Back door key lock and unlock switch 6. Door courtesy switch circuit 7. Back door courtesy switch circuit 8. Engine hood courtesy switch circuit	05–1802 05–1805 05–1726 73–5 73–5 05–1794 05–1794 05–1809
Security indicator light does not blink when theft deterrent system is set	1. Security indicator light circuit	05–1802
Alarm sounding state is not canceled when ignition switch is turned ON–OFF 10 times within 15 seconds	1. Ignition switch circuit 2. Un–lock warning switch circuit	05–1807 05–1726
Theft deterrent system can be set even when any door is open	1. Door courtesy switch circuit	05–1794
Horn (low pitched, high pitched) does not sound while theft deterrent system is in warning operation	1. Horn (low pitched, high pitched) circuit	–
Headlights do not flash while theft deterrent system is in warning operation (Except Europe)	1. Headlight circuit	05–1374
Taillights do not flash while theft deterrent system is in warning operation (Except Europe)	1. Taillights circuit	05–1367
Hazard warning lights do not flash while theft deterrent system is in warning operation	1. Hazard warning switch	65–2
Room lamp does not flash while theft deterrent system is in warning operation	1. Room lamp circuit	05–1381
Theft deterrent horn does not sound while theft deterrent system is in warning operation (Except Europe)	1. Theft deterrent horn circuit	05–1812
Theft deterrent siren sounds even when theft deterrent system is not set (Europe only)	1. Theft deterrent siren circuit	05–1812
Headlights flash even when theft deterrent system is not set (Except Europe)	1. Headlight circuit	05–1374
Taillights flash even when theft deterrent system is not set (Except Europe)	1. Taillights circuit	05–1367
Hazard warning lights flash even when theft deterrent system is not set	1. Hazard warning switch circuit	65–2
Room lamp flashes even when theft deterrent system is not set	1. Room lamp circuit	05–1381
Theft warning siren sounds even when theft deterrent system is not set (Europe only)	1. Theft deterrent siren circuit	05–1812
Intrusion sensor does not detect any moving object while theft deterrent system is set (Europe only)	1. Instrution sensor circuit	05–1815
Intrusion sensor sets off alarm while theft deterrent system is not set or there is nothing moving inside vehicle with theft deterrent system set (Europe only)	1. Intrusion sensor circuit	05–1815

Intrusion sensor OFF switch does not operate (Europe only)	1. Intrusion sensor circuit	05–1815
Intrusion sensor OFF switch continues operating (Europe only)	1. Intrusion sensor circuit	05–1815