05AEQ–01

DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during the DTC check, check the circuit listed for that code in the chart below (Proceed to the page given for that circuit).

DTC No. (See page)	Detection Item	Trouble Area
B1211 (05–1831)	Driver Door ECU Communication Stop	• Power window regulator master switch assy (Driver door ECU) • Wire harness
B1214 (05–1835)	Door System Communicatin Bus Malfunction (+B Short)	• Power window regulator master switch assy (Driver door ECU) • Theft warning ECU assy (Theft deterrent ECU) • Door opening relay assy (Double locking ECU) • Instrument panel junction block assy (Body ECU) • Wire harness
B1215 (05–1835)	Door System Communicatin Bus Malfunction (GND Short)	• Power window regulator master switch assy (Driver door ECU) • Theft warning ECU assy (Theft deterrent) • Door opening relay assy (Double locking ECU) • Instrument panel junction block assy (Body ECU) • Wire harness
B1249 (05–1841)	Double Locking ECU Communication Stop	• Door opening relay assy (Double locking ECU) • Wire harness
B1269 (05–1845)	Theft Deterrent ECU Communication Stop	• Theft warning ECU assy (Theft deterrent ECU) • Wire harness