05AER–01

PROBLEM SYMPTOMS TABLE

1. TROUBLESHOOTING FOR EACH PROBLEM SYMPTOM

NOTICE:

Confirm the problem symptom and make an inspection depending on the applicable flowchart.

Symptom	Suspected Area	See Page
B1211 (No communication from driver door ECU for more than 10 seconds)	1. Power window regulator master switch assy (Driver door ECU) 2. Wire harness	05–1831 –
B1214 (Short in communication circuit and +B power source system)	1. Power window regulator master switch assy (Driver door ECU) 2. Theft warning ECU assy (Theft deterrent ECU) 3. Door opening relay assy (Double locking ECU) 4. Instrument panel junction block assy (Body ECU) 5. Wire harness	05–1831 05–1845 05–1841 – –
B1215 (Short in communication circuit and body ground)	1. Power window regulator master switch assy (Driver door ECU) 2. Theft warning ECU assy (Theft deterrent ECU) 3. Door opening relay assy (Double locking ECU) 4. Instrument panel junction block assy (Body ECU) 5. Wire harness	05–1831 05–1845 05–1841 – –
B1249 (No communication from double locking ECU more than 10 seconds.)	1. Door opening relay assy (Double locking ECU) 2. Wire harness	05–1841 –
B1269 (No communication from theft deterrent ECU for more than 10 seconds)	1. Theft warning ECU assy (Theft deterrent ECU) 2. Wire harness	05–1845 –