056HH–02

# DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is indicated during the DTC check, check the circuit listed for that code in the table below, and proceed to the appropriate page.

| DTC No. (See Page) | Circuit Inspection | Trouble Area |
|---|---|---|
| 21 (05–1862) | Vehicle Speed Sensor Circuit Malfunction | • Combination meter assy<br>• Vehicle speed sensor<br>• Vehicle speed sensor circuit<br>• ECM |
| 23 (05–1862) | | |
| 32*1 (05–1863) | Cruise Control Main Switch Circuit Malfunction | • Cruise control main switch<br>• Cruise control main switch circuit<br>• ECM |
| 52 (05–1865) | Stop Light Switch Circuit Malfunction | • Stop lamp switch assy<br>• Stop lamp switch assy circuit<br>• ECM |
| 54 (05–1869) | Input Signal Circuit Malfunction | • ECM |
| 55 (05–1869) | | |

HINT:

*1: DTC 32 is output only for vehicle with a 1KZ–TE engine.